

Programmable Controllers

COMPANY

MITSUBISHI ELECTRIC CORP
2-7-3 MARUNOUCHI
CHIYODA-KU, TOKYO 100-8310 Japan

E95239

View model for additional information

Model(s): [GT27-VHOUT](#)

A Series adapter modules, Model(s): [A1ADP-SP](#), [A1ADP-XY](#)

A Series base units, Model(s): [A32B-UL](#), [A35B-UL](#), [A38B-UL](#), [A55B-UL](#), [A58B-UL](#), [A65B-UL](#), [A8B-UL](#)

A Series battery cables, Model(s): [AC08BAT](#)

A Series battery modules, Model(s): [A10BAT](#), [A10BAT-S1](#), [A8BAT](#)

A Series connection cables, Model(s): [A1SC01B](#), [A1SC03B](#), [A1SC05NB](#), [A1SC07B](#), [A1SC12B](#), [A1SC20B-S1](#), [A1SC30B](#), [A1SC50B](#), [A1SC60B](#), [AC06B-UL](#), [AC12B-UL](#), [AC30B-UL](#), [AC30R4-PUS](#)

A Series CPU modules, Model(s): [A1SCPU](#), [A1SCPU-S1](#), [A1SHCPU](#), [A1SJCPU](#), [A1SJCPU-S3](#), [A1SJHCPU](#), [A1SJHCPU-S8](#), [A2ASCPU](#), [A2ASCPU-M128](#), [A2ASCPU-S1](#), [A2ASCPU-S30](#), [A2ASCPU-S60](#), [A2NCPU-UL](#), [A2SCPU](#), [A2SCPU-S1](#), [A2SHCPU](#), [A2SHCPU-S1](#), [A2USCPU](#), [A2USCPU-M128](#), [A2USCPU-S1](#), [A2USCPU-S30](#), [A2USCPU-S60](#), [A2USHCPU-S1](#), [A3NCPU-UL](#)

A Series CPU modules, Model(s): [A](#) , followed by 2, 3 or 4, followed by A or U, followed by CPU, may be followed by P21 or R21, followed by -UL, may be followed by -S1.

A Series extension base units, Model(s): [A1S32B](#), [A1S33B](#), [A1S35B](#), [A1S38B](#), [A1S52B](#), [A1S52B-S1](#), [A1S55B](#), [A1S55B-S1](#), [A1S58B](#), [A1S58B-S1](#), [A1S65B](#), [A1S65B-S1](#), [A1S68B](#), [A1S68B-S1](#)

A Series I/O modules, Model(s): [A1SX10EU](#), [A1SX20EU](#), [A1SY10EU](#), [A1SY14EU](#), [A1SY18AEU](#), [A1SY28EU](#)

A Series input modules, Model(s): [A1S42X](#), [A1SH42P](#), [A1SH42P-S1](#), [A1SH42-S1](#), [A1SH42X](#), [A1SH42Y](#), [A1SJ-56DR](#), [A1SJ-56DT](#), [A1SX10](#), [A1SX20](#), [A1SX30](#), [A1SX40](#), [A1SX40-S1](#), [A1SX40-S2](#), [A1SX41](#), [A1SX41-S2](#), [A1SX42](#), [A1SX42-S1](#), [A1SX42-S2](#), [A1SX48Y18](#), [A1SX48Y58](#), [A1SX71](#), [A1SX80](#), [A1SX80-S1](#), [A1SX80-S2](#), [A1SX81](#), [A1SX81-S2](#), [A1SX82-S1](#), [AX10-UL](#), [AX11EU](#), [AX20-UL](#), [AX21EU](#), [AX40-UL](#), [AX41-UL](#), [AX70-UL](#), [AX80-UL](#)

A Series memory cassettes, Model(s): [A1SMCA-2KE](#), [A1SMCA-8KE](#), [A1SMCA-8KP](#), [A1SNMCA-2KE](#), [A1SNMCA-8KE](#), [A1SNMCA-8KP](#), [A2SMCA-14KE](#), [A2SMCA-14KP](#), [A2SNMCA-30KE](#), [A3NMCA0-UL](#), [A3NMCA16-UL](#), [A3NMCA24-UL](#), [A3NMCA2-UL](#), [A3NMCA40-UL](#), [A3NMCA4-UL](#), [A3NMCA8-UL](#)

A Series output modules, Model(s): [A1SY10](#), [A1SY18A](#), [A1SY22](#), [A1SY28A](#), [A1SY40](#), [A1SY40P](#), [A1SY41](#), [A1SY41P](#), [A1SY42](#), [A1SY42P](#), [A1SY42Y](#), [A1SY50](#), [A1SY60](#), [A1SY60E](#), [A1SY68A](#), [A1SY71](#), [A1SY80](#), [A1SY81](#), [A1SY82](#), [AY10A-UL](#), [AY11-UL](#), [AY15EU](#), [AY20EU](#), [AY40-UL](#), [AY41-UL](#), [AY50-UL](#), [AY51-UL](#), [AY60S-UL](#), [AY70-UL](#)

A Series power supply modules, Model(s): [A1S61PN](#), [A1S62P](#), [A1S62PN](#), [A61PEU](#), [A61PN](#), [A61P-UL](#), [A62PEU](#), [A67RP](#)

A Series pressure programming units, Model(s): [A7PUS](#)

A Series special function modules, Model(s): [A1S62DA](#), [A1S62RD3](#), [A1S62RD4](#), [A1S63ADA](#), [A1S64AD](#), [A1S64TCTRT](#), [A1S64TCTRTBW](#), [A1SD51S](#), [A1SD51S-S1](#), [A1SD61](#), [A1SD61-S2](#), [A1SD70](#), [A1SD71-S2](#), [A1SD71-S7](#), [A1SG60](#), [A1SG62](#), [A1SI61](#), [A1SJ71AP21](#), [A1SJ71AP21Q](#), [A1SJ71AP21-S3](#), [A1SJ71AP23Q](#), [A1SJ71AR21](#), [A1SJ71AR21Q](#), [A1SJ71AR23Q](#), [A1SJ71AS92](#), [A1SJ71AT21B](#), [A1SJ71AT21BQ](#), [A1SJ71AT23BQ](#), [A1SJ71C24-PREF](#), [A1SJ71C24-R2](#), [A1SJ71C24-R4](#), [A1SJ71DN91](#), [A1SJ71E71N3-T](#), [A1SJ71E71N-B2](#), [A1SJ71E71N-B5](#), [A1SJ71E71N-B5T](#), [A1SJ71E71N-T](#), [A1SJ71LR21](#), [A1SJ71PB92D](#), [A1SJ71PB93D](#), [A1SJ71PB96F](#), [A1SJ71PT32-S3](#), [A1SJ71T21B](#), [A1SJ71UC24-PREF](#), [A1SJ71UC24-R2](#), [A1SJ71UC24-R2-S2](#), [A1SJ71UC24-R4](#), [A1SJ71UC24-R4-S2](#), [A1SJ72T25B](#), [A1SP60](#), [A1ST60](#), [A68RD3N](#), [A68RD4N](#), [AIS62DA](#), [AIS62LS](#), [AIS62RD3](#), [AIS62RD3N](#), [AIS62RD4](#), [AIS62RD4N](#), [AIS62TCRTBW-S2](#), [AIS62TCTR-S2](#), [AIS62TCTTBW-S2](#), [AIS62TCTT-S2](#), [AIS63ADA](#), [AIS64AD](#), [AIS64TCRTBW-S1](#), [AIS64TCRT-S1](#), [AIS64TCTTBW-S1](#), [AIS64TCTT-S1](#), [AIS68AD](#), [AIS68DAI](#), [AIS68DAV](#), [AIS68TD](#), [AISD51S](#), [AISD51S-S1](#), [AISD52-S1](#), [AISD52-S2](#), [AISD61](#), [AISD62](#), [AISD62D](#), [AISD62D-S1](#), [AISD62E](#), [AISD70](#), [AISD71-S2](#), [AISD71-S7](#), [AISD75M1](#), [AISD75M2](#), [AISD75M3](#), [AISD75P1-S3](#), [AISD75P2-S3](#), [AISD75P3-S3](#), [AJ71DN91](#), [AJ71QLP21S](#), [AJ71QLR21](#), [AJ71UC24](#), [AJ71UC24-S2](#), [AJ72QLR25](#)

A/D Conversion Units, Model(s): [L60ADVL8](#), [L60ADVL8-CM](#), [L60ADIL8](#), [L60ADIL8-CM](#)

A/D, D/A Conversion Unit, Model(s): [L60AD2DA2-CM](#), [L60AD2DA2-Fnn](#), [L60AD2DA2](#)

A/D, D/A Conversion Unit, Model(s): [L60AD2DA2-Fnn-CM](#) (where "nn" is an optional two character alphanumeric suffix signifying changes in software)

A2C Series CPU modules, Model(s): [A2CCPU](#), [A2CCPUC24](#), [A2CCPUC24-PREF](#), [A2CCPUP21](#), [A2CCPUR21](#)

A2C Series I/O modules, Model(s): [AX10Y10C](#), [AX10Y22C](#), [AX40Y10C](#), [AX40Y50C](#), [AX80Y10C](#), [AX80Y80C](#)

A2C Series input modules, Model(s): [AX11C](#), [AX41C](#), [AX81C](#)

A2C Series output modules, Model(s): [AY13C](#), [AY23C](#), [AY51C](#), [AY81C](#)

A2C Series power supply modules, Model(s): [A66PC](#)

A2C Series special function modules, Model(s): [A64DAIC](#), [A64DAVC](#), [A64RD3C](#), [A64RD4C](#), [A68ADC](#), [AD61C](#)

Accessories, current sensors, Model(s): [EMU2-CT5](#), [EMU2-CT5-4W](#), [EMU-CT100](#), [EMU-CT250](#), [EMU-CT400-A](#), [EMU-CT50](#), [EMU-CT600-A](#)

Accessories, extended SRAM units, Model(s): [Q4MCA-1MBS](#), [Q4MCA-2MBS](#), [Q4MCA-4MBS](#), [Q4MCA-8MBS](#)

Accessory Adapter Modules, "FX5 Series", Model(s): [FX5-232ADP](#), [FX5-485ADP](#)

Accessory Cable, Model(s): [GT14H-C30-25PDI](#)

Accessory Connector Conversion Adapter, Model(s): [FX5-CNV-BUS](#)

Accessory Extended SRAM Unit, "MELSEC", Model(s): [NZ2MC-1MBS](#), [NZ2MC-2MBS](#), [NZ2MC-2MBSE](#), [NZ2MC-4MBS](#), [NZ2MC-8MBS](#)

Accessory External Connection Cable, Model(s): [GT11H-C**](#) where ** is 30, 60, 100, 150, 200 or 300, and may be followed by 37P.

Accessory External Connection Cable, Model(s): [GT16H-C**-37PE](#) where ** is 30, 60, 100, 150, 200 or 300.

Accessory GOT2000 Series Accessory Units, Model(s): [GT16M-MMR-Z](#), [GT16M-R2-Z](#), [GT16M-ROUT-Z](#), [GT16M-V4R1-Z](#), [GT16M-V4-Z](#)

Accessory I/O Units, Model(s): [LY18R2A](#), [LY18R2A-CM](#), [LY28S1A](#), [LY28S1A-CM](#)

Accessory Intelligent Function module, "FX5 Series", Model(s): [FX5-CCLIEF](#)

Accessory Intelligent Function Module, "MELSEC iQ-F", Model(s): [FX5-160SSC-G](#) may be followed by - BS., [FX5-40SSC-G](#) may be followed by - BS., [FX5-40SSC-S](#) may be followed by - BS., [FX5-80SSC-G](#) may be followed by - BS., [FX5-80SSC-S](#) may be followed by - BS.

Accessory Connector Conversion Adapter of programmable controller, Model(s): [FX3S-](#) followed by [CNV-ADP](#) suffix

Accessory Enclosed Connector Box Unit, Model(s): [GT16H-CNB-37S**](#) series where * is optional and may be 0 to 9 incl., A to Z incl.

Accessory Enclosed External Connection Cable, Model(s): [GT14H-C**-42P](#) where ** is 30, 60, 100, 150, 200 or 300.

Accessory Open type, Model(s): [GT25-J71E71-100](#), [NZ2MC-8MBSE](#), [NZ2MC-16MBS](#), [RC80B](#)

Accessory Open type CFast Card, "MELSEC", Model(s): [NZ1MEM-16GBCFT](#), [NZ1MEM-32GBCFT](#), [NZ1MEM-64GBCFT](#)

Accessory Open type RS-422/485 Conversion Adapter, Model(s): [L6ADP-R4](#), [L6ADP-R4-CM](#)

Accessory Open type, "Graphic Operation Terminal", Model(s): [GT27-V4R1-Z](#), [GT25-WLAN](#)

Accessory SD Card Unit, Model(s): [GT21-03SDCD**](#), where * is optional and may be 0 to 9 incl., A to Z incl.

Accessory, "MELSEC iQ-R", Model(s): [RC06B](#), [RC100B](#), [RC12B](#), [RC30B](#), [RC50B](#)

Adaptor modules, Model(s): [A6ADP-1MC16D](#), [A6ADP-1MC16T](#), [A6ADP-2MC16D](#)

AL2 Series adapter modules, Model(s): [AL2-2PT-ADP](#), [AL2-2TC-ADP](#)

AL2 Series application programmable controllers, Model(s): [AL2-10MR-A](#), [AL2-10MR-D](#), [AL2-14MR-A](#), [AL2-14MR-D](#), [AL2-24MR-A](#), [AL2-24MR-D](#)

AL2 Series expansion modules, Model(s): [AL2-2DA](#), [AL2-4EX](#), [AL2-4EX-A2](#), [AL2-4EYR](#), [AL2-4EYT](#)

Alpha Series programmable controllers, Model(s): [AL](#), followed by 6MR, 10MR, 10MT, 20MR or 20MT, followed by -A or -D, may be followed by -001.

Analog multiplex modules, Model(s): [A60MXRN](#), [A60MXR-S1](#), [A60MXTN](#), [A60MXT-S1](#)

Base, "MELSEC iQ-R", Model(s): [R66WRB-HT](#), [R68WRB](#)

Battery cables, Model(s): [QC10BAT](#)

Battery units, Model(s): [Q170BAT](#), [Q170DBATC](#), [Q170HBATC](#)

Book type I/O Unit, Model(s): [FCU7DX078](#), [FCU7DX079](#)

Box Data Logger module, Model(s): [NZ2DL](#)

C Language Controller Interface Module, Model(s): [Q173SCCF](#), [Q173SCCF-Snn](#)

CC-Link IE Controller Network Interface board, Model(s): [NZ81GP21-SX-F10](#)

CC-link IE controller networks, Model(s): [GT15-J71GP23-SX](#)

CC-Link IE Field Network Basic Remote I/O Module, Model(s): [NZ2MF2S2-16A](#), [NZ2MF2S2-16R](#)

CC-Link IE Field Network Remote device Temperature Control Module, "CC-Link IE Field Network Remote Device Temperature", Model(s): [NZ2GF2B-60TCRT4](#), [NZ2GF2B-60TCTT4](#)

CC-Link IE Field Network Remote Multi Input Module, Model(s): [NZ2GF2S-60MD4](#)

CC-link IE field networks, Model(s): [GT15-J71GF13-T2](#)

CC-Link IE TSN Remote I/O Module, Model(s): [NZ2GNSS2-16DTE-K](#), [NZ2GNSS2-8D-K](#), [NZ2GNSS2-8TE-K](#)

CC-Link IE TSN Remote I/O module, "MELSEC", Model(s): [NZ2GN12A2-16T](#), [NZ2GN12A2-16TE](#), [NZ2GN12A4-16D](#), [NZ2GN12A4-16DE](#), [NZ2GN12A42-16DT](#), [NZ2GN12A42-16DTE](#), [NZ2GNS12A2-14DT](#), [NZ2GNS12A2-16DTE](#)

CC-Linkmaster-local Series modules, Model(s): [A1SJ61BT11](#), [A1SJ61QBT11](#), [AJ61BT11](#), [AJ61QBT11](#)

CL1 Series adapters, Model(s): [CL1-PAD1](#)

CL1 Series cables, Model(s): [CL1-X2-D1D3S](#), [CL1-X2-DE1D3S](#), [CL1-XY2-DT1D5S](#), [CL1-XY2-DTE1D5S](#), [CL1-Y2-T1D2S](#), [CL1-Y2-TE1D2S](#)

CL1 Series CC-link/LT I/O modules, Model(s): [CL2](#) , followed by X, Y or XY, followed by 8 or 16, followed by -D, -DTP, -TP or -TPE, followed by 1, followed by B, C, M, MJ or S, followed by 1, 2, 3 or 5, followed by non or V.

CL1 Series CC-link/LT remote analog modules, Model(s): [CL2](#), followed by AD or DA, followed by 4 or 2, followed by -B

CL1 Series programmable controllers, Model(s): [CL1-PSU-2A](#), [CL1-X4-D1C3](#), [CL1-X4-D1S2](#), [CL1-X4-T1C2](#), [CL1-X4-T1S2](#)

CL1 Series terminals, Model(s): [CL1-X4-D1B2](#), [CL1-XY4-DR1B2](#), [CL1-XY4-DT1B2](#), [CL1-XY4-DTE162](#), [CL1-XY8-DR1B2](#), [CL1-XY8-DT1B2](#), [CL1-XY8-DTE1B2](#), [CL1-Y4-R1B1](#), [CL1-Y4-R1B2](#), [CL1-Y4-T1B2](#), [CL1-Y4-TE1B2](#)

Code Reader, Model(s): [CF37](#) or [CF37 SENSOR](#) may be followed by additional suffixes

CompactFlash cards for high speed data logger modules, Model(s): [QD81MEM-1GBC](#), [QD81MEM-2GBC](#), [QD81MEM-4GBC](#), [QD81MEM-512MBC](#), [QD81MEM-8GBC](#)

Connector Conversion Adapter, Model(s): [FX5-CNV-IFC](#) may be followed by additional alphanumeric suffix

CPU models, Model(s): [Q12DCCPU-V-Bnnn](#) (Bundle Variant three character alphanumeric suffix)

CPU modules, Model(s): [Q24DHCCPU-LS-H01](#)

CPU modules, Model(s): [Q24DHCCPU-LS-Bnnn](#) (Bundle Variant three character alphanumeric suffix)

Dividing units, Model(s): [MR-MV200](#), [Q173DHDV](#), [Q173DHDV-S1](#), [Q173DV](#), [Q173DV-S1](#), [Q173DV-S2](#)

Enclosed, Programmable controllers, Model(s): [FCU7-DA938X-42](#), [NZ2GF12A-60IOLH8](#)

Enclosed, Programmable controllers, "FCU7", Model(s): [FCU7-CM141-0S](#), [FCU7-DU140-01](#), [FCU7-DU140-1S](#), [FCU7-DU140-3S](#)

Enclosed, Programmable controllers, "Graphic Operation Terminal", Model(s): [GT145*HS-Q*BDE**](#) series where * is optional and may be 0 to 9 incl., A to Z incl.

Enclosed, Programmable controllers, "Graphic Operation Terminal", Model(s): [GT2107-WT*D**](#) where * is optional and may be 0 to 9 incl., A to Z incl

Enclosed, Programmable controllers, "Graphic Operation Terminal", Model(s): [GT2507-WT*D-***](#) where * is optional and may be 0 to 9 incl., A to Z incl.

Enclosed, Programmable controllers, "Graphic Operation Terminal", Model(s): [GT2510-WXT*D-***](#) where * is optional and may be 0 to 9 incl., A to Z incl.

Enclosed, Programmable controllers, "GT", Model(s): [GT2505-VT*D****](#) where * is optional and may be 0 to 9 incl., A to Z incl.

Energy measuring units, Model(s): [QE81WH](#), [QE81WH4W](#), [QE83WH4W](#), [QE84WH](#)

Energy saving data collecting servers, "EcoServerIII", Model(s): [MES3-255C](#)

Energy saving data collecting servers, "EcoWebServerIII", Model(s): [MES3-255C-CN](#), [MES3-255C-EN](#)

Eprom write adaptors, Model(s): [A2SWA-28P](#), [A6WA-28P](#)

Ethernet interface units, Model(s): [LJ71E71-100](#), [LJ71E71-100-CM](#)

Ethernet modules, Model(s): [AJ71E71N3-T](#), [AJ71E71N-B2](#), [AJ71E71N-B5](#), [AJ71E71N-B5T](#), [AJ71QE71N3-T](#), [AJ71QE71N-B2](#), [AJ71QE71N-B5](#), [AJ71QE71N-B5T](#)

Expansion units, Model(s): [IU2-12B-E](#)

Extension units, Model(s): [F1-10ER-UL](#), [F1-20ER-UL](#), [F1-40ER-UL](#), [F1-60ER-UL](#), [F-20ER-UL](#), [F2-40ER-UL](#), [F2-40MR-D](#), [F2-60ER-UL](#), [F-40ER-UL](#), [MATRIX NEXUS II](#)

FCU7 Series book type I/O units, Model(s): [FCU7-7DX078](#), [FCU7-7DX079](#)

FCU7 Series CNC control units, Model(s): [FCU7-HN633-04](#), [FCU7-HN633-05](#), [FCU7-HN653-05](#), [FCU7-MA041](#), [FCU7-MA541](#), [FCU7-MU031](#), [FCU7-MU041](#), [FCU7-MU531](#), [FCU7-MU541](#), [FCU7-MU551](#), [FCU7-MU552](#), [FCU7-MU553](#), [FCU7-MU554](#), [FCU7-MU556](#), [FCU7-MU557](#), [FCU7-MU558](#), [FCU7-MU561-84](#), [FCU7-MU562-64](#), [FCU7-MU571-64](#), [FCU7-MU571-75](#)

FCU7 Series CNC Listed Accessory: Extension Unit, Model(s): [FCU7-HN749](#)

FCU7 Series display units, Model(s): [FCU7-CM121-02](#), [FCU7-CM141-01](#), [FCU7-DA435-01](#), [FCU7--DA435-11](#), [FCU7-DA435-11S](#), [FCU7--DA435-21](#), [FCU7--DA435-23](#), [FCU7-DA435-33S](#), [FCU7-DA435-61](#), [FCU7-DA435-63](#), [FCU7-DA435-63S](#), [FCU7-DA435-71](#), [FCU7-DA435-73](#), [FCU7-DA435-73S](#), [FCU7-DA435X-02](#), [FCU7-DA636-11](#), [FCU7-DA636-11S](#), [FCU7-DA636-31](#), [FCU7-DA636-33S](#), [FCU7-DA636-73S](#), [FCU7-DA646-11](#), [FCU7-DA646-11S](#), [FCU7-DA646-31](#), [FCU7-DA646-33S](#), [FCU7-DA737-01](#), [FCU7-DA737-11](#), [FCU7-DA737-11S](#), [FCU7-DA737-23](#), [FCU7-DA737-33](#), [FCU7-DA737-33S](#), [FCU7-DA737-73](#), [FCU7-DA737-73S](#), [FCU7-DA747-01](#), [FCU7-DA747-11](#), [FCU7-DA747-23](#), [FCU7-DA747-33](#), [FCU7-DU120-02](#), [FCU7-DU120-11](#), [FCU7-DU120-13](#), [FCU7-DU140-11](#), [FCU7-DU140-22](#), [FCU7-DU140-31](#), [FCU7-YZ131](#), [FCU7-YZ132](#), [FCU7-YZ143](#), [FCU7-YZ144](#), [FCU7-YZ191](#), [FCU7-YZ192](#), [FCU7-YZ193](#), [FCU7-YZ194](#)

FCU7 Series keyboard units, Model(s): [FCU7-KB028](#), [FCU7-KB042](#), [FCU7-KB043](#), [FCU7-KB046](#), [FCU7-KB047](#), [FCU7-KB048](#), [FCU7-YZ031](#), [FCU7-YZ032](#), [FCU7-YZ041](#), [FCU7-YZ091](#)

FCU7 Series Listed Accessory: Extension Unit, Model(s): [FCU7-EX891](#), [FCU7-HN538](#), [FCU7-HN571](#), [FCU7-HN576](#), [FCU7-HN577](#), [FCU7-HN693](#), [FCU7-HN698](#), [FCU7-HN721](#), [FCU7-HN722](#), [FCU7-HN741](#), [FCU7-HN745](#), [FCU7-HN746](#), [FCU7-HN747](#), [FCU7-HN748](#), [FCU7-HN754](#), [FCU7-Matrix Nexus II](#)

FCU7 Series operation panel I/O units, Model(s): [FCU7-DX621](#), [FCU7-HN376-02](#)

Flash cards, Model(s): [GT05-MEM-128MC](#), [GT05-MEM-16GC](#), [GT05-MEM-16MC](#), [GT05-MEM-1GC](#), [GT05-MEM-256MC](#), [GT05-MEM-2GC](#), [GT05-MEM-32MC](#), [GT05-MEM-4GC](#), [GT05-MEM-512MC](#), [GT05-MEM-64MC](#), [GT05-MEM-8GC](#), [GT05-MEM-ADPC](#)

Flexible High-Speed I/O controller, Model(s): [RD40PD01](#)

FX Series expansion units, Model(s): [FX-16EYT-ESS/UL](#), [FX-8ER-ES/UL](#), [FX-8EYS-ES/UL](#), [FX-8EYT-ESS/UL](#)

FX Series extension blocks, Model(s): [FX-16E-TB](#), [FX-16EX-A1-TB](#), [FX-16EX-ES/UL](#), [FX-16EYR-ES/UL](#), [FX-16EYR-TB](#), [FX-16EYS-ES/UL](#), [FX-16EYT-TB](#), [FX-32E-TB](#), [FX-8EX-ES/UL](#), [FX-8EX-UA1/UL](#), [FX-8EYR-ES/UL](#)

FX Series external terminal blocks, Model(s): [FX-16E-TB/UL](#), [FX-16EX-A1-TB/UL](#), [FX-16EYR-ES-TB/UL](#), [FX-16EYS-ES-TB/UL](#), [FX-16EYT-ESS-TB/UL](#), [FX-16EYT-ES-TB/UL](#), [FX-32E-TB/UL](#)

FX Series handy programming panels, Model(s): [FX-30P](#)

FX Series programmable controllers, Model(s): [FX-128MR-ES/UL](#), [FX-128MT-ESS/UL](#), [FX-16MR-ES/UL](#), [FX-16MT-ESS/UL](#), [FX-24MR-ES/UL](#), [FX-24MR-UA1/UL](#), [FX-24MT-ESS/UL](#), [FX-32ER-ES/UL](#), [FX-32MR-ES/UL](#), [FX-32MT-ESS/UL](#), [FX-48ER-ES/UL](#), [FX-48ER-UA1/UL](#), [FX-48ET-ESS/UL](#), [FX-48MR-ES/UL](#), [FX-48MR-UA1/UL](#), [FX-48MT-ESS/UL](#), [FX-64MR-ES/UL](#), [FX-64MR-UA1/UL](#), [FX-64MT-ESS/UL](#), [FX-80MR-ES/UL](#), [FX-80MT-ESS/UL](#)

FX1N Series programmable controllers, Model(s): [FX1N-14MR](#), [FX1N-14MR-D](#), [FX1N-14MR-DS](#), [FX1N-14MR-ES/UL](#), [FX1N-14MT](#), [FX1N-14MT-D](#), [FX1N-14MT-DSS](#), [FX1N-14MT-ESS/UL](#), [FX1N-20MR-D](#), [FX1N-24MR](#), [FX1N-24MR-DS](#), [FX1N-24MR-ES/UL](#), [FX1N-24MT](#), [FX1N-24MT-D](#), [FX1N-24MT-DSS](#), [FX1N-24MT-ESS/UL](#), [FX1N-40MR-D](#), [FX1N-40MR-DS](#), [FX1N-40MT-D](#), [FX1N-40MT-DSS](#), [FX1N-60MR-D](#), [FX1N-60MR-DS](#), [FX1N-60MT-D](#), [FX1N-60MT-DSS](#), [FX1N-60MT-TKL](#)

FX1S Series programmable controllers, Model(s): [FX1S-10MR](#), [FX1S-10MR-D](#), [FX1S-10MR-DS](#), [FX1S-10MR-ES](#), [FX1S-10MR-ES/UL](#), [FX1S-10MT](#), [FX1S-10MT-D](#), [FX1S-10MT-DSS](#), [FX1S-10MT-ESS/UL](#), [FX1S-14MR](#), [FX1S-14MR-D](#), [FX1S-14MR-DS](#), [FX1S-14MR-ES](#), [FX1S-14MR-ES/UL](#), [FX1S-14MT](#), [FX1S-14MT-D](#), [FX1S-14MT-DSS](#), [FX1S-14MT-ESS/UL](#), [FX1S-14MT-SK](#), [FX1S-20MR](#), [FX1S-20MR-D](#), [FX1S-20MR-DS](#), [FX1S-20MR-ES](#), [FX1S-20MR-ES/UL](#), [FX1S-20MT](#), [FX1S-20MT-D](#), [FX1S-20MT-D-SK](#), [FX1S-20MT-DSS](#), [FX1S-20MT-ESS/UL](#), [FX1S-20MT-SK](#), [FX1S-30MR](#), [FX1S-30MR-D](#), [FX1S-30MR-DS](#), [FX1S-30MR-ES](#), [FX1S-30MR-ES/UL](#), [FX1S-30MT](#), [FX1S-30MT-D](#), [FX1S-30MT-DSS](#), [FX1S-30MT-ESS/UL](#)

FX2C Series programmable controllers, Model(s): [FX2C-128MT-E/UL](#), [FX2C-128MT-ESS/UL](#), [FX2C-160MT-E/UL](#), [FX2C-160MT-ESS/UL](#), [FX2C-64MT-E/UL](#), [FX2C-64MT-ESS/UL](#), [FX2C-96MT-E/UL](#), [FX2C-96MT-ESS/UL](#)

FX2N Series expansion units, Model(s): [FX2N-8ER-ES/UL](#), [FX2N-8EX-ES/UL](#), [FX2N-8EX-UA1/UL](#), [FX2N-8EYR-ES/UL](#), [FX2N-8EYT-ESS/UL](#)

FX2N Series extension blocks, Model(s): [FX2N-16EX-ES/UL](#), [FX2N-16EYR-ES/UL](#), [FX2N-16EYS](#), [FX2N-16EYT-ESS/UL](#), [FX2N-8EYR-S-ES/UL](#)

FX2N Series power supply units, Model(s): [FX2N-20PSU](#)

FX2N Series programmable controllers, Model(s): [FX2N-128MR-ES/UL](#), [FX2N-128MT-ESS/UL](#), [FX2N-16MR-DS](#), [FX2N-16MR-ES/UL](#), [FX2N-16MR-UA1/UL](#), [FX2N-16MT-DSS](#), [FX2N-16MT-E/UL](#), [FX2N-16MT-ESS/UL](#), [FX2N-32ER-ES/UL](#), [FX2N-32ET-ESS/UL](#), [FX2N-32MR-DS](#), [FX2N-32MR-ES/UL](#), [FX2N-32MR-UA1/UL](#), [FX2N-32MS-E/UL](#), [FX2N-32MT-DSS](#), [FX2N-32MT-E/UL](#), [FX2N-32MT-ESS/UL](#), [FX2N-48ER-DS](#), [FX2N-48ER-ES/UL](#), [FX2N-48ER-UA1/UL](#), [FX2N-48ET-DSS](#), [FX2N-48ET-ESS/UL](#), [FX2N-48MR-ES/UL](#), [FX2N-48MR-UA1/UL](#), [FX2N-48MS-E/UL](#), [FX2N-48MT-DSS](#), [FX2N-48MT-E/UL](#), [FX2N-48MT-ESS/UL](#), [FX2N-64MR-DS](#), [FX2N-64MR-ES/UL](#), [FX2N-64MR-UA1/UL](#), [FX2N-64MT-DSS](#), [FX2N-64MT-ESS/UL](#), [FX2N-80BMTNC](#), [FX2N-80MR-DS](#), [FX2N-80MR-ES/UL](#), [FX2N-80MT-DSS](#), [FX2N-80MT-ESS/UL](#)

FX2N Series special function blocks, Model(s): [FX2N-16LNK-M](#), [FX2N-2LC-/UL](#), [FX2N-5A](#), [FX2N-64CL-M](#), [FX2N-64DNET](#), [FX2N-64DP-M](#), [FX2N-8AD](#)

FX2N Series special function blocks, Model(s): [FX2N](#) -, followed by 2AD, 2DA, 4AD, 4DA, 1PG-E, 10PG, 1HC or 20GM, may be followed by -PT or -TC, may be followed by -E.

FX2NC Series adapters, Model(s): [FX2NC-ENET-ADP](#)

FX2NC Series extension blocks, Model(s): [FX2NC-16EX](#), [FX2NC-16EX-D/UL](#), [FX2NC-16EX-DS](#), [FX2NC-16EX-T](#), [FX2NC-16EXT-DS](#), [FX2NC-16EYR-T](#), [FX2NC-16EYRT-DS](#), [FX2NC-16EYT](#), [FX2NC-16EYT-D/UL](#), [FX2NC-16EYT-DSS](#), [FX2NC-32EX](#), [FX2NC-32EX-D/UL](#), [FX2NC-32EX-DS](#), [FX2NC-32EYT](#), [FX2NC-32EYT-D/UL](#), [FX2NC-32EYT-DSS](#)

FX2NC Series programmable controllers, Model(s): [FX2NC-16MRT-DS](#), [FX2NC-16MT-D/UL](#), [FX2NC-32MT-D/UL](#), [FX2NC-64MT-D/UL](#), [FX2NC-96MT-D/UL](#)

FX2NC Series special function blocks, Model(s): [FX2NC-1HC](#), [FX2NC-4AD](#), [FX2NC-4DA](#)

FX3G Series connector conversion adapters, Model(s): [FX3G-CNV-ADP](#)

FX3G Series I/O modules, Model(s): [FX3G](#) -, followed by 14MT, 24MT, 40MT, 60MT, 14MR, 24MR, 40MR or 60 MR, followed by /ES, /ESS, /DS or /DSS suffix, may be followed by -A.

FX3U Series adapters, Model(s): [FX3U-232ADP#](#), [FX3U-232ADP-MB#](#), [FX3U-232ADP-MBH#](#), [FX3U-2HSY-ADP#](#), [FX3U-3A-ADP#](#), [FX3U-485-ADP#](#), [FX3U-485ADP-MB#](#), [FX3U-485ADP-MBH#](#), [FX3U-4AD-ADP#](#), [FX3U-4AD-PT-ADP#](#), [FX3U-4AD-TC-ADP#](#), [FX3U-4DA-ADP#](#), [FX3U-4HSX-ADP#](#), [FX3U-CF-ADP#](#)

FX3U Series power supply units, Model(s): [FX3U-1PSU-5V](#)

FX3U Series programmable controllers, Model(s): [FX3U-32MS-/ES#](#), [FX3U-64MS-/ES#](#)

FX3U Series programmable controllers, Model(s): [FX3U](#) -, followed by 16MT, 32MT, 48MT, 64MT, 80MT or 128MT, followed by /DS, /DSS, /ES or /ESS, may be followed by -A.#

FX3U Series programmable controllers, Model(s): [FX3U-](#) -, followed by 16MR, 32MR, 48MR, 64MR, 80MR, 128MR, followed by /DS, /ES or /UA1, may be followed by -A.#

FX3U Series special adapter modules, Model(s): [FX3U-ENET-ADP](#)

FX3U Series special function blocks, Model(s): [FX3U-1PG](#), [FX3U-2HC](#), [FX3U-32DP](#), [FX3U-4AD](#), [FX3U-4DA](#), [FX3U-4LC](#), [FX3U-64DP-M#](#)

FX3U Series special function units, Model(s): [FX3U-CAN](#), [FX3U-ENET#](#), [FX3U-J1939](#)

FX3U Series special function units, for communicating with SSCNET III, Model(s): [FX3U-2OSSC-H](#)

FX3UC Series power supplies and conversion cards, Model(s): [FX3UC-1PS-5V](#)

FX3UC Series programmable controllers, Model(s): [FX3UC-16MR-/DS-T](#), [FX3UC-16MR-/D-T](#)

FX3UC Series special function blocks, Model(s): [FX3UC-16MT-/D](#), [FX3UC-16MT-/DSS](#), [FX3UC-32MT-/D](#), [FX3UC-32MT-/DSS](#), [FX3UC-4AD](#), [FX3UC-64MT-/D](#), [FX3UC-64MT-/DSS](#), [FX3UC-96MT-/D](#), [FX3UC-96MT-/DSS](#)

FXO Series programmable controllers, Model(s): [FXO-14MR-ES/UL](#), [FXO-14MT-E/UL](#), [FXO-20MR-ES/UL](#), [FXO-20MT-E/UL](#), [FXO-30MR-ES/UL](#), [FXO-30MT-E/UL](#)

FXON Series expansion units, Model(s): [FXON-16EX-ES/UL](#), [FXON-16EYR-ES/UL](#), [FXON-16EYS-ES/UL](#), [FXON-16EYT-ESS/UL](#), [FXON-8ER-ES/UL](#), [FXON-8EYR-ES/UL](#), [FXON-8EYS-ES/UL](#), [FXON-8EYT-ESS/UL](#)

FXON Series programmable controllers, Model(s): [FXON-24MR-ES/UL](#), [FXON-24MR-UA1/UL](#), [FXON-40ER-ES/UL](#), [FXON-40ER-UA1/UL](#), [FXON-40MR-ES/UL](#), [FXON-40MR-UA1/UL](#), [FXON-60MR-ES/UL](#), [FXON-60MR-UA1/UL](#)

FXON Series special function blocks, Model(s): [FXON-32NT-DP](#)

FXOS Series programmable controllers, Model(s): [FXOS-10MR-ES/UL](#), [FXOS-10MR-ES/UL-BS](#), [FXOS-14MR-ES/UL](#), [FXOS-16MR-UA1/UL](#), [FXOS-20MR-ES/UL](#), [FXOS-24MR-UA1/UL](#), [FXOS-30MR-ES/UL](#)

Gateways, Model(s): [NZ2AW1C1BY](#), [NZ2AW1C2AL](#), [NZ2AW1GFAL](#)

GOT1000 Series graphic operation terminals, Model(s): [GT1150-QLBDA](#), [GT1150-QLBDQ](#), [GT1155-QSBDA](#), [GT1155-QSBDQ](#), [GT1155-QTBDA](#), [GT1155-QTBDQ](#), [GT1165-VNBA-C](#), [GT1265-VNBA](#), [GT1265-VNBD](#), [GT1275-VNBA](#), [GT1275-VNBD](#), [GT1550-QLBD](#), [GT1555-QSBD](#), [GT1555-QTBD](#), [GT1555-VTBD](#), [GT1562-VNBA](#), [GT1562VNBD](#), [GT1565-VNBA](#), [GT1565-VNBD](#), [GT1565-VTBA](#), [GT1565-VTBD](#), [GT1572-VNBA](#), [GT1572-VNBD](#), [GT15-75ABUS2L](#), [GT15-75ABUSL](#), [GT15-75IF900](#), [GT15-75J61BT13-Z](#), [GT15-75J71BR13-Z](#), [GT15-75J71LP23-Z](#), [GT15-75QBUS2L](#), [GT15-75QBUSL](#), [GT1575-STBA](#), [GT1575-STBD](#), [GT1575-VNBA](#), [GT1575-VNBD](#), [GT1575-VTBA](#), [GT1575-VTBA-010](#), [GT1675M-VTBA-010](#), [GT1575-VTBD](#), [GT1585-STBA](#), [GT1585-STBD](#), [GT1595-XTBA](#), [GT1595-XTBD](#), [GT15-ABUS](#), [GT15-ABUS2](#), [GT15-CFCD](#), [GT15-CFEX-C08SET](#), [GT15-DIO](#), [GT15-DIOR](#), [GT15-FNB](#), [GT15-J71E71-100](#), [GT15-QBUS](#), [GT15-QBUS2](#), [GT15-QFNB](#), [GT15-QFNB16M](#), [GT15-QFNB32M](#), [GT15-QFNB48M](#), [GT15-RS2-9P](#), [GT15-RS2T4-25P](#), [GT15-RS2T4-9P](#), [GT15-RS4-9S](#), [GT15-RS4-TE](#), [GT15-SOUT](#), [GT15-VHNB](#), [GT15-XHNB](#), [GT1655-VTBD](#), [GT1655-VTBD-120](#), [GT1662-VNBA](#), [GT1662-VNBD](#), [GT1665M-STBA](#), [GT1665M-STBA-120](#), [GT1665M-STBD](#), [GT1665M-STBD-120](#), [GT1665M-VTBA](#), [GT1665M-VTBA-120](#), [GT1665M-VTBD](#), [GT1665M-VTBD-120](#), [GT1672-VNBA](#), [GT1672-VNBD](#), [GT1675M-STBA](#), [GT1675M-STBA-120](#), [GT1675M-STBA-140](#), [GT1675M-STBD](#), [GT1675M-STBD-120](#), [GT1675M-VTBA](#), [GT1675M-VTBA-120](#), [GT1675M-VTBA-140](#), [GT1675M-VTBD](#),

GT1675M-VTBD-120, GT1675-VNBA, GT1675-VNBA-140, GT1675-VNBD, GT1685M-STBA, GT1685M-STBA-120, GT1685M-STBA-140, GT1685M-STBD, GT1685M-STBD-120, GT1695M-XTBA, GT1695M-XTBA-120, GT1695M-XTBD, GT1695M-XTBD-120, GT16-MESB, GT16M-MMR, GT16M-R2, GT16M-ROUT, GT16M-V4, GT16M-V4R1

GOT2000 Graphic Operation Terminal, Model(s): GT2308-VTBA, GT2308-VTBD, GT2310-VTBA, GT2310-VTBD

GOT2000 Series accessory units, Model(s): GT27-IF1000, GT27-MMR-Z, GT27-R2-Z, GT27-ROUT-Z, GT27-V4-Z

GOT2000 Series graphic operation terminals, Model(s): GT2508-VTBA-160, GT2508-VTBA-160, GT2508-VTBD-160, GT2508-VTBD-160, GT2510-VTBA-020, GT2510-VTBA-160, GT2510-VTBA-160, GT2510-VTBD-020, GT2510-VTBD-160, GT2510-VTBD-160, GT2512-STBA-020, GT2512-STBA-160, GT2512-STBA-160, GT2512-STBD-020, GT2512-STBD-160, GT2512-STBD-160, GT2705-VTBD, GT2705-VTBD-160, GT2705-VTBD-160, GT2708-STBA, GT2708-STBA-010, GT2708-STBA-160, GT2708-STBA-160, GT2708-STBD, GT2708-STBD-160, GT2708-STBD-160, GT2708-VTBA, GT2708-VTBA-160, GT2708-VTBA-160, GT2708-VTBD, GT2708-VTBD-160, GT2708-VTBD-160, GT2710-STBA, GT2710-STBA-010, GT2710-STBA-020, GT2710-STBA-160, GT2710-STBA-160, GT2710-STBD, GT2710-STBD-020, GT2710-STBD-160, GT2710-STBD-160, GT2710-VTBA, GT2710-VTBA-020, GT2710-VTBA-160, GT2710-VTBA-160, GT2710-VTBD, GT2710-VTBD-020, GT2710-VTBD-160, GT2710-VTBD-160, GT2710-VTWA, GT2710-VTWD, GT2712-STBA, GT2712-STBA-010, GT2712-STBA-020, GT2712-STBA-120, GT2712-STBA-160, GT2712-STBA-160, GT2712-STBD, GT2712-STBD-020, GT2712-STBD-120, GT2712-STBD-160, GT2712-STBD-160, GT2712-STWA, GT2715-XTBA-160, GT2715-XTBA-160, GT2715-XTBD-160, GT2715-XTBD-160

Graphic Operation terminal, Model(s): GT1450-QMBD

Graphic Operation Terminal, Model(s): GT1450-QMBDE

Graphic Operation Terminal, Model(s): GT2104 followed by -R, followed by -T, followed by -B or -W, followed by -D, may be followed by nothing or -, may be followed by -* where * is optional and may be 0 to 9 incl., A to Z incl.

Graphic operation terminals, Model(s): F9040GOT-SWD-E, F920GOT-BBD5-K, F920GOT-BBD5-K-C, F920GOT-BBD5-K-E, F920GOT-BBD-K, F920GOT-BBD-K-C, F920GOT-BBD-K-E, F930GOT-BBD-K, F930GOT-BBD-K-C, F930GOT-BBD-K-E, F930GOT-BBD-K-T, F930GOT-BWD, F930GOT-BWD-C, F930GOT-BWD-E, F930GOT-BWD-T, F940GOT-LWD, F940GOT-LWD-C, F940GOT-LWD-E, F940GOT-SWD, F940GOT-SWD-C, F940WGOT-TWD, F940WGOT-TWD-C, F940WGOT-TWD-E, GT1020-LBD+, GT1020-LBD2+, GT1020-LBDW+, GT1020-LBDW2+, GT1020-LBL+, GT1020-LBL2+, GT1020-LBLW+, GT1020-LBLW2+, GT1020-LWD+, GT1020-LWD2+, GT1020-LWDW+, GT1020-LWDW2+, GT1020-LWL+, GT1020-LWL2+, GT1020-LWLW+, GT1020-LWLW2+, GT1020-LWLW2-C+, GT1020-MBDW-SK+, GT1030-HBD+, GT1030-HBD2+, GT1030-HBDW+, GT1030-HBDW2+, GT1030-HBL+, GT1030-HBL2+, GT1030-HBLW+, GT1030-HBLW2+, GT1030-HWD+, GT1030-HWD2+, GT1030-HWDW+, GT1030-HWDW2+, GT1030-HWL+, GT1030-HWL2+, GT1030-HWLW+, GT1030-HWLW2+, GT1030-LBD+, GT1030-LBD2+, GT1030-LBDW+, GT1030-LBDW2+, GT1030-LBL+, GT1030-LBL2+, GT1030-LBLW+, GT1030-LBLW2+, GT1030-LWD+, GT1030-LWD2+, GT1030-LWDW+, GT1030-LWDW2+, GT1030-LWL+, GT1030-LWL2+, GT1030-LWLW+, GT1150-QBBD*, GT1150-QBBD06*, GT1150-QBWD*, GT1150-QBWD-C*, GT1150-QLBD*, GT1150-QLBD06*, GT1150-QLWD*, GT1150-QLWD-C*, GT1155-QBBD-C*, GT1155-QLBD-C*, GT1155-QSBD*, GT1155-QSBD06*, GT1155-QSBD-C*, GT1155-QSBD-LTI*, GT1155-QSWD*, GT1155-QSWD-C*, GT1155-QTBD*, GT1155-QTBD06*, GT1155-QTBD-C*, GT1155-QTWD*, GT1155-QTWD-C*

Graphic operation terminals, Model(s): GT2103-PM***** where * is optional and may be 0 to 9 incl., A to Z incl., or hyphen

GT Series accessories, connector box units, Model(s): GT16H-CNB-42S*

GT Series accessories, external connection cables, Model(s): GT16H-C followed by 30, 60, 100, 150, 200 or 300, may be followed by -42P.

GT Series graphic operation terminals, Model(s): GT1665HS-VTBD*

GT1040-QBBD Series graphic operation terminals, Model(s): GT1040 followed by Q, followed by S, followed by B or W, followed by D, may be followed by 06, 09 or two alphanumerics, may be followed by -C.

GT1045-QBSD Series graphic operation terminals, Model(s): GT1045- followed by Q, followed by S, followed by B or W, followed by D, may be followed by 06, 09 or two alphanumerics, may be followed by -C.

GT1050-QBBD Series graphic operation terminals, Model(s): [GT1050-QBBD](#), [GT1050-QBBD06](#), [GT1050-QBBD06-C](#), [GT1050-QBBD09](#), [GT1050-QBBD09-C](#), [GT1050-QBBD-C](#)

GT1050-QBWD Series graphic operation terminals, Model(s): [GT1050-QBWD](#), [GT1050-QBWD06](#), [GT1050-QBWD06-C](#), [GT1050-QBWD09](#), [GT1050-QBWD09-C](#), [GT1050-QBWD-C](#)

GT1050-QLBD Series graphic operation terminals, Model(s): [GT1050-QLBD](#), [GT1050-QLBD06](#), [GT1050-QLBD06-C](#), [GT1050-QLBD09](#), [GT1050-QLBD09-C](#), [GT1050-QLBD-C](#)

GT1050-QLWD Series graphic operation terminals, Model(s): [GT1050-QLWD](#), [GT1050-QLWD06](#), [GT1050-QLWD06-C](#), [GT1050-QLWD09](#), [GT1050-QLWD09-C](#), [GT1050-QLWD-C](#)

GT1055-QSBD Series graphic operation terminals, Model(s): [GT1055-QSBD](#), [GT1055-QSBD06](#), [GT1055-QSBD06-C](#), [GT1055-QSBD09](#), [GT1055-QSBD09-C](#), [GT1055-QSBD-C](#)

GT1055-QSWD Series graphic operation terminals, Model(s): [GT1055-QSWD](#), [GT1055-QSWD06](#), [GT1055-QSWD06-C](#), [GT1055-QSWD09](#), [GT1055-QSWD09-C](#), [GT1055-QSWD-C](#)

GT145 Series programmable controllers, Model(s): [GT1450-QLBD*](#), [GT1450-QLBDE*](#), [GT1455-QTBD*](#), [GT1455-QTBDE*](#)

GT145 Series RS485 conversion adapters, Model(s): [GT14-RS2T4-9P](#)

Handy graphic operation terminals, Model(s): [A950GOT-LBD-M3-H](#), [A950GOT-SBD-B](#), [A950GOT-SBD-M3-B](#), [A950GOT-SBD-M3-H](#), [A951GOT-QSBD-B](#), [A951GOT-QSBD-M3-B](#), [A951GOT-SBD-B](#), [A951GOT-SBD-M3-B](#), [A953GOT-LBD-M3-H](#), [A953GOT-SBD-B](#), [A953GOT-SBD-M3-B](#), [A953GOT-SBD-M3-H](#), [A956GOT-SBD-B](#), [A956GOT-SBD-M3-B](#), [F940GOT-LBD-H](#), [F940GOT-LBD-H-C](#), [F940GOT-LBD-H-E](#), [F940GOT-SBD-H](#), [F940GOT-SBD-H-C](#), [F940GOT-SBD-H-E](#), [F943GOT-LBD-H](#), [F943GOT-LBD-H-C](#), [F943GOT-LBD-H-E](#), [F943GOT-SBD-H](#), [F943GOT-SBD-H-C](#), [F943GOT-SBD-H-E](#), [GT1150HS-QLBD*](#), [GT1150HS-QLBD04*](#), [GT1150HS-QLBD07*](#), [GT1150HS-QLBD08*](#), [GT1150HS-QLBDH1*](#), [GT1150HS-QLBDH2*](#), [GT1150-QLBDNS*](#), [GT11550HS-QLBD*](#), [GT1155HS-QSBD*](#), [GT1155HS-QSBD01*](#), [GT1155HS-QSBD02*](#), [GT1155HS-QSBD04*](#), [GT1155HS-QSBD07*](#), [GT1155HS-QSBD08*](#), [GT1155HS-QSBDHK*](#), [GT1155HS-QSBDHM*](#), [GT1155HS-QSBDLI*](#), [GT1155HS-QSBDNS](#), [GT1155HS-QSBDTB*](#), [GT1155HS-QSBDTE*](#), [GT1155HS-QSBDTL1*](#)

I/O link Series master modules, Model(s): [A1SJ51T64](#)

I/O Units, Model(s): [LH42C4NT1P](#), [LH42C4NT1P-CM](#), [LH42C4PT1P](#), [LH42C4PT1P-CM](#)

Increase boards, Model(s): [IU2-16EAD-20M](#), [IU2-16EDIO-CMOS](#), [IU2-16EDIO-CPTR](#), [IU2-16EIB-CP](#), [IU2-18EAD-100H](#), [IU2-2E232-115K](#), [IU2-2E232-38K](#), [IU2-2E485-38K](#), [IU2-2EAD-110H](#), [IU2-32EDIO-CMOS](#), [IU2-32EDIO-CPTR](#), [IU2-4ECN-10M](#), [IU2-64EDI-CMOS](#), [IU2-64EDI-CP](#), [IU2-64EDO-CMOS](#), [IU2-64EDO-TR](#), [IU2-8EDA-100M](#), [IU2-8EIB-TR](#), [IU2-EBR1-50](#), [IU2-EBR2-50](#), [IU2-IEGPIB](#)

Industrial Ethernet Switch, Model(s): [NZ2MHG-TSNT4](#), [NZ2MHG-TSNT8F2](#)

Insulation monitor units, Model(s): [QE82LG](#)

Intelligent inspection units, Model(s): [IU2-4M10HA-E](#), [IU2-5M10-E](#)

Interface units, Model(s): [FX2N-32DP-IF](#)

Manual pulse generators, "Melsec-Q Series", Model(s): [Q173PX-S1](#)

MELSEC iQ-R Series, MELSECNET/H modules, Model(s): [RJ71LP21-25](#)

Melsec-A Series control and communication link system boards, Model(s): [A80BDE-J61BT11](#), [A80BDE-J61BT13](#)

Melsec-A Series CPU boards, Model(s): [A80BDE-A2USH-S1](#)

Melsec-A Series network boards, Model(s): [A70BDE-J71QBR13](#), [A70BDE-J71QLP23](#), [A70BDE-J71QLP23GE](#), [A70BDE-J71QLR23](#)

Melsec-A Series SSC I/F boards, Model(s): [A10BD-PCF](#)

Melsec-iQ-R Series CPU modules, Model(s): [Model\(s\) R16MTCPU, R32MTCPU and R64MTCPU](#)

Melsec-iQ-R Series positioning modules, Model(s): [RD77MS16, RD77MS16-APnnn, RD77MS2, RD77MS4, RD77MS8](#)

MELSEC-iQ-R Series, Distributor Module, Model(s): [R60AD6-DG](#)

Melsec-L Series A/D conversion units, Model(s): [L60AD24-2GH-CM, L60AD4, L60AD4-2GH, L60AD4-2GH-CM, L60AD4-CM](#)

Melsec-L Series accessories, extension cables, Model(s): [LC06E, LC06E-CM, LC10E, LC10E-CM, LC30E, LC30E-CM](#)

Melsec-L Series branch units, Model(s): [L6EXB, L6EXB-CM](#)

Melsec-L Series CC-link IE field network communication head units, Model(s): [LJ72GF15-T2, LJ72GF15-T2-CM](#)

Melsec-L Series CC-link IE field network master/local units, Model(s): [LJ71GF11-T2, LJ71GF11-T2-CM](#)

Melsec-L Series CC-link system master/local units, Model(s): [LJ61BT11, LJ61BT11-CM](#)

Melsec-L Series CC-link/LT master units, Model(s): [LJ61CL12, LJ61CL12-CM](#)

Melsec-L Series CPU units, Model(s): [L02CPU, L02CPU-CM, L02CPU-P, L02SCPU, L02SCPU-CM, L02SCPU-P, L26CPU, L26CPU-BT, L26CPU-BT-CM, L26CPU-CM, L26CPU-P, L26CPU-PBT, L26CPU-PBT-CM](#)

Melsec-L Series D/A conversion units, Model(s): [L60DA4, L60DA4-CM, L60DAVL8\(-CM\), L60DAIL8\(-CM\)](#)

Melsec-L Series display units, Model(s): [L6DSPU, L6DSPU-C-CM](#)

Melsec-L Series END covers, Model(s): [L6EC, L6EC-CM, L6EC-ET, L6EC-ET-CM](#)

Melsec-L Series extension units, Model(s): [L6EXE, L6EXE-CM](#)

Melsec-L Series high-speed counter units, Model(s): [LD62, LD62-CM, LD62D, LD62D-CM](#)

Melsec-L Series I/O units, Model(s): [LX10, LX10-CM, LX28, LX28-CM, LX40C6, LX40C6-CM, LX41C4, LX41C4-CM, LX42C4, LX42C4-CM, LY10R2, LY10R2-CM, LY20S6, LY20S6-CM, LY40NT5P, LY40NT5P-CM, LY40PT5P, LY40PT5P-CM, LY41NT1P, LY41NT1P-CM, LY41PT1P, LY41PT1P-CM, LY42NT1P, LY42NT1P-CM, LY42PT1P, LY42PT1P-CM](#)

Melsec-L Series position units, Model(s): [LD75D1, LD75D1-CM, LD75D2, LD75D2-CM, LD75D4, LD75D4-CM, LD75P1, LD75P1-CM, LD75P2, LD75P2-CM, LD75P4, LD75P4-CM](#)

Melsec-L Series power supply units, Model(s): [L61P, L61P-CM, L63P, L63P-CM](#)

MELSEC-L series programmable controllers, Model(s): [L06CPU@, L06CPU-APnnn@, L06CPU-CM@, L06CPU-P@](#)

Melsec-L Series RS-232 adapters, Model(s): [L6ADP-R2, L6ADP-R2-CM](#)

Melsec-L Series serial communication units, Model(s): [LJ71C24, LJ71C24-CM, LJ71C24-R2, LJ71C24-R2-CM](#)

Melsec-L Series temperature control units, Model(s): [L60TCRT4, L60TCRT4BW, L60TCRT4BW-CM, L60TCRT4-CM, L60TCTT4, L60TCTT4BW, L60TCTT4BW-CM, L60TCTT4-CM](#)

Melsec-NC Series CC-link bridge modules, Model(s): [NZ2GF-CCB](#)

Melsec-NZ Series CC-link IE field network ethernet adapter units, Model(s): [NZ2GF-ETB](#)

Melsec-NZ Series CC-link IE field network remote device A/D conversion modules, Model(s): [NZ2GF2B-60AD4](#)

Melsec-NZ Series CC-link IE field network remote device D/A conversion modules, Model(s): [NZ2GF2B-60DA4](#)

Melsec-NZ Series CC-link IE field network remote device high speed counter modules, Model(s): [NZ2GFCF-D62PD2](#)

Melsec-NZ Series CC-link IE field network remote I/O modules, Model(s): [NZ2EX2B1-16D](#), [NZ2EX2B1-16T](#), [NZ2EX2B1-16TE](#), [NZ2GF2B1-16D](#), [NZ2GF2B1-16T](#), [NZ2GF2B1-16TE](#), [NZ2GF2B1N-16D](#), [NZ2GF2B1N-16T](#), [NZ2GF2B1N-16TE](#), [NZ2GFCE3-16D](#), [NZ2GFCE3-16DE](#), [NZ2GFCE3-16T](#), [NZ2GFCE3-16TE](#), [NZ2GFCM1-16D](#), [NZ2GFCM1-16DE](#), [NZ2GFCM1-16T](#), [NZ2GFCM1-16TE](#)

Melsec-Q Series A/D conversion modules, Model(s): [Q64AD](#), [Q64AD-FAM](#), [Q64AD-GH](#), [Q64ADH](#), [Q68AD-G](#), [Q68ADI](#), [Q68ADV](#)

Melsec-Q Series A/D, D/A conversion modules, Model(s): [Q64AD2DA](#)

Melsec-Q Series adaptor modules, Model(s): [QA6ADP](#)

Melsec-Q Series AS-i master modules, Model(s): [QJ71AS92](#)

Melsec-Q Series base units, Model(s): [Q1712B](#), [Q175B](#), [Q178B](#), [Q312B](#), [Q312B-E](#), [Q312DB](#), [Q32SB](#), [Q32SB-E](#), [Q33B](#), [Q33B-E](#), [Q33SB](#), [Q33SB-E](#), [Q35B](#), [Q35B-E](#), [Q35B-FAM](#), [Q35BL](#), [Q35BL-E](#), [Q35BLS](#), [Q35BLS-D](#), [Q35DB](#), [Q35SB](#), [Q35SB-E](#), [Q38B](#), [Q38B-E](#), [Q38BL](#), [Q38BL-E](#), [Q38BLS](#), [Q38BLS-D](#), [Q38DB](#), [Q38RB](#), [Q38RB-E](#), [Q38SB-E](#), [Q52B](#), [Q55B](#), [Q55BL](#), [Q55BL-E](#), [Q55BLS](#), [Q55BLS-D](#), [Q612B](#), [Q63B](#), [Q65B](#), [Q65BL](#), [Q65BL-E](#), [Q65BLS](#), [Q65BLS-D](#), [Q65WRB](#), [Q68B](#), [Q68BL](#), [Q68BL-E](#), [Q68BLS](#), [Q68BLS-D](#), [Q68RB](#), [QA1S33B](#), [QA1S33B-E](#), [QA1S35B](#), [QA1S35B-E](#), [QA1S38B](#), [QA1S38B-E](#), [QA1S51B](#), [QA1S65B](#), [QA1S68B](#), [QA65B](#), [QA65B-E](#), [QA68B](#), [QA68B-E](#)

Melsec-Q Series battery modules, Model(s): [Q8BAT](#)

Melsec-Q Series CC-link IE controller network interface boards, Model(s): [Q80BD-J71GP21-SX](#), [Q81BD-J71GP21-SX](#)

Melsec-Q Series CC-link IE controller network interface boards with external power supplies, Model(s): [Q80BD-J71GP21S-SX](#), [Q81BD-J71GP21S-SX](#)

Melsec-Q Series CC-link IE field network interface boards, Model(s): [Q81BD-J71GF11-T2](#) and [Q80BD-J71GF11-T2](#)

Melsec-Q Series CC-Link IE field network master/local modules, Model(s): [QJ71GF11-T2](#)

Melsec-Q Series CC-Link master-local modules, Model(s): [QJ61BT11](#), [QJ61BT11N](#)

Melsec-Q Series CC-link Ver.2 embedded interface boards, Model(s): [Q50BD-CCV2](#)

Melsec-Q Series CC-link Ver.2 system boards, Model(s): [NZ81GP21-SX](#), [Q80BD-J61BT11N](#), [Q81BD-J61BT11](#)

Melsec-Q Series computer link (basic language) modules, Model(s): [QD51](#), [QD51-R24](#)

Melsec-Q Series computer link modules, Model(s): [QJ71C24](#), [QJ71C24N](#), [QJ71C24N-R2](#), [QJ71C24N-R4](#), [QJ71C24-R2](#), [QJ71E71-B5](#)

Melsec-Q Series CPU modules, Model(s): [MR-MQ100](#), [Q00CPU](#), [Q00JCPU](#), [Q00JCPU-E](#), [Q00JCPU-PW](#), [Q00JCPU-S8](#), [Q00UCPU](#), [Q00UJCPU](#), [Q00UJCPU-S8](#), [Q01BCPU-H10](#), [Q01BCPU-H11](#), [Q01CPU](#), [Q01UCPU](#), [Q02CPU](#), [Q02CPU-A](#), [Q02HCPU](#), [Q02HCPU-A](#), [Q02HCPU-FAM](#), [Q02PHCPU](#), [Q02UCPU](#), [Q03UDCPU](#), [Q03UDECPU](#), [Q03UDVCPU](#), [Q04UDEHCPU](#), [Q04UDHCPU](#), [Q04UDPVCPU](#), [Q04UDVCPU](#), [Q06CCPU-Q-H01](#), [Q06CCPU-V](#), [Q06CCPU-V-B](#), [Q06CCPU-V-H01](#), [Q06HCPU](#), [Q06HCPU-A](#), [Q06PHCPU](#), [Q06UDEHCPU](#), [Q06UDHCPU](#), [Q06UDPVCPU](#), [Q06UDVCPU](#), [Q100UDEHCPU](#), [Q10UDEHCPU](#), [Q10UDHCPU](#), [Q12DCCPU-V](#), [Q12HCPU](#), [Q12PHCPU](#), [Q12PRHCPU](#), [Q13UDEHCPU](#), [Q13UDHCPU](#), [Q13UDPVCPU](#), [Q13UDVCPU](#), [Q170MCP](#), [Q170MCP-S1](#), [Q170MSCPU](#), [Q170MSCPU-S1](#), [Q172CPU](#), [Q172CPUN](#), [Q172CPUN-S2](#), [Q172CPUN-T](#), [Q172DCPU](#), [Q172DCPU-S1](#), [Q172DCPU-S2](#), [Q172DCPU-T](#), [Q172DCPU-T-S0](#), [Q172DSCPU](#), [Q172HCPU](#), [Q172HCPU-S5](#), [Q172HCPU-T](#), [Q173CPU](#), [Q173CPUN](#), [Q173CPUN-S1](#), [Q173CPUN-T](#), [Q173CPU-S1](#), [Q173DCPU](#), [Q173DCPU-S1](#), [Q173DCPU-T](#), [Q173DCPU-T-S0](#), [Q173DSCPU](#), [Q173HCPU](#), [Q173HCPU-S1](#), [Q173HCPU-T](#), [Q173NCCPU](#), [Q20UDEHCPU](#), [Q20UDHCPU](#), [Q24DHCCPU](#), [Q25HCPU](#), [Q25PHCPU](#), [Q25PRHCPU](#), [Q26UDEHCPU](#), [Q26UDHCPU](#), [Q26UDPVCPU](#), [Q26UDVCPU](#), [Q50UDEHCPU](#), [QO2UCPU-F10](#)

Melsec-Q Series CPU modules, Model(s): [Q24DHCCPU-V-Bnnn](#) (Bundle Variant three character alphanumeric suffix)

Melsec-Q Series current transformer input modules, Model(s): [Q68CT](#)

Melsec-Q Series D/A conversion modules, Model(s): [Q62DA](#), [Q62DA-FG](#), [Q62DAN](#), [Q64DA](#), [Q64DAH](#), [Q64DAN](#), [Q66DA-G](#), [Q68DAI](#), [Q68DAIN](#), [Q68DAV](#), [Q68DAVN](#)

Melsec-Q Series data collection server modules, Model(s): [QJ71DS96-H10](#)

Melsec-Q Series DeviceNet master-slave modules, Model(s): [QJ71DN91](#)

Melsec-Q Series distributor modules, Model(s): [Q62AD-DGH](#), [Q66AD-DG](#)

Melsec-Q Series dual signal modules, Model(s): [Q173DSXY](#), [Q173SXY](#)

Melsec-Q Series Ethernet modules, Model(s): [QJ71E71](#), [QJ71E71-100](#), [QJ71E71-B2](#), [QJ71EIP71](#), [QJ71ST11-100](#)

Melsec-Q Series extension cables, Model(s): [QC05B](#), [QC06B](#), [QC100B](#), [QC12B](#), [QC30B](#), [QC40B](#), [QC50B](#)

Melsec-Q Series FL net modules, Model(s): [QJ71FL71](#), [QJ71FL71-B2](#), [QJ71FL71-B2-Fnn](#), [QJ71FL71-B5](#), [QJ71FL71-B5-Fnn](#), [QJ71FL71-Fnn](#), [QJ71FL71-T](#), [QJ71FL71-T-Fnn](#)

Melsec-Q Series heater bus interface modules, Model(s): [Q172HBF](#)

Melsec-Q Series high speed counter modules, Model(s): [QD62](#), [QD62D](#), [QD62E](#), [QD62-H01](#), [QD62-H02](#), [QD63P6](#), [QD64D2](#)

Melsec-Q Series high speed data communication modules, Model(s): [QJ71DC96](#), [QJ71DC96-F01](#)

Melsec-Q Series high speed data logger modules, Model(s): [QD81DL96](#)

Melsec-Q Series high speed intercept modules, Model(s): [QI60](#)

Melsec-Q Series I/O modules, Model(s): [Q42X-H01](#), [Q42Y-H01](#), [QH42P](#), [QH42P-FAM](#), [QH48Y57](#), [QX10](#), [QX10-TS](#), [QX11L](#), [QX28](#), [QX40](#), [QX40H](#), [QX40-S1](#), [QX40-TS](#), [QX41](#), [QX41-S1](#), [QX41-S2](#), [QX41Y41P](#), [QX42](#), [QX42-S1](#), [QX50](#), [QX70](#), [QX70H](#), [QX71](#), [QX72](#), [QX80](#), [QX80H](#), [QX80-TS](#), [QX81](#), [QX81-S2](#), [QX82](#), [QX82-S1](#), [QX90H](#), [QY10](#), [QY10-TS](#), [QY13L](#), [QY18A](#), [QY22](#), [QY40P](#), [QY40P-TS](#), [QY41H](#), [QY41P](#), [QY42P](#), [QY50](#), [QY68A](#), [QY70](#), [QY71](#), [QY80](#), [QY80-TS](#), [QY81P](#), [QY82P](#)

Melsec-Q Series intelligent (C language) modules, Model(s): [QD54-S1](#)

Melsec-Q Series isolated pulse input modules, Model(s): [QD60P8-G](#)

Melsec-Q Series loadcell input modules, Model(s): [Q61LD](#)

Melsec-Q Series Loop control modules, Model(s): [Q62HLC](#)

Melsec-Q Series manual pulse generators, Model(s): [Q173DPX](#), [Q173PX](#)

Melsec-Q Series memory card units, Model(s): [Q2MEM-16MBA](#), [Q2MEM-1MBS](#), [Q2MEM-1MBSN](#), [Q2MEM-2MBF](#), [Q2MEM-2MBS](#), [Q2MEM-2MBSN](#), [Q2MEM-32MBA](#), [Q2MEM-4MBF](#), [Q2MEM-8MBA](#), [Q3MEM-4MBA](#), [Q3MEM-4MBS](#), [Q3MEM-8MBA](#), [Q3MEM-8MBS](#)

Melsec-Q Series MES (Manufacturing Execution System) interface modules, Model(s): [QD81MES96](#), [QJ71MES96](#)

Melsec-Q Series Modbus modules, Model(s): [QJ71MB91](#), [QJ71MT91](#)

Melsec-Q Series multi function counter/timer modules, Model(s): [QD65PD2](#)

Melsec-Q Series net link boards, Model(s): [QJ71BR11](#), [QJ71GP21S-SX](#), [QJ71GP21-SX](#), [QJ71LP21](#), [QJ71LP21-25](#), [QJ71LP21G](#), [QJ71LP21GE](#), [QJ71LP21S-25](#), [QJ71NT11B](#), [QJ72BR15](#), [QJ72LP25-25](#), [QJ72LP25G](#), [QJ72LP25GE](#)

Melsec-Q Series network boards, Model(s): [Q80BD-J71LP21S-25](#)

Melsec-Q Series network interface boards, Model(s): [Q80BD-J71BR11](#), [Q80BD-J71LP21-25](#), [Q81BD-J71LP21-25](#)

Melsec-Q Series Nexus modules, Model(s): [QJ71E71-100-F10](#)

Melsec-Q Series positioning modules, Model(s): [QD70D4](#), [QD70D4-H10](#), [QD70D8](#), [QD70D8-H10](#), [QD70P4](#), [QD70P8](#), [QD72P3C3](#), [QD73A1](#), [QD74MH8](#), [QD75D1](#), [QD75D1-F01](#), [QD75D1N](#), [QD75D2](#), [QD75D2N](#), [QD75D4](#), [QD75D4N](#), [QD75M1](#), [QD75M2](#), [QD75M4](#), [QD75MH1](#), [QD75MH2](#), [QD75MH4](#), [QD75P1](#), [QD75P1N](#), [QD75P2](#), [QD75P2N](#), [QD75P4](#), [QD75P4N](#), [QD77GF16](#), [QD77GF4](#), [QD77GF8](#), [QD77MS16](#), [QD77MS2](#), [QD77MS4](#)

Melsec-Q Series power supplies, Model(s): [Q61P](#), [Q61P-A1](#), [Q61P-A2](#), [Q61P-D](#), [Q61P-HAM](#), [Q61SP](#), [Q62P](#), [Q64P](#), [Q64PN](#), [Q64RP](#)

Melsec-Q Series Profibus network modules, Model(s): [QJ71PB92D](#), [QJ71PB92V](#), [QJ71PB93D](#)

Melsec-Q Series Pt100 input modules (3-wire type/4 wire type), Model(s): [Q64RD](#), [Q64RD-F10](#), [Q64RD-G](#), [Q64RD-G-F10](#), [Q68RD3-G](#)

Melsec-Q Series RS232 cables, Model(s): [Q12DCCPU-CBL](#), [QC30R2](#)

Melsec-Q Series SEC LCD network modules, Model(s): [QJ71SE91-F01](#)

Melsec-Q Series servos external signal modules, Model(s): [Q172DLX](#), [Q172LX](#)

Melsec-Q Series synchronous encoders, Model(s): [Q170ENC](#), [Q171ENC](#), [Q171ENC-W8](#), [Q172DEX](#), [Q172DEX-S1](#), [Q172DEX-S2](#), [Q172DEX-S3](#), [Q172EX](#), [Q172EX-S1](#), [Q172EX-S2](#), [Q172EX-S3](#), [Q370ENC](#)

Melsec-Q Series temperature and mV/digital conversion modules, Model(s): [Q64TDV-GH](#), [Q64TDV-GH-F10](#)

Melsec-Q Series temperature control modules, Model(s): [Q64TCRT](#), [Q64TCRTBW](#), [Q64TCRTBWN](#), [Q64TCRTN](#), [Q64TCTT](#), [Q64TCTTBW](#), [Q64TCTTBWN](#), [Q64TCTTN](#)

Melsec-Q Series temperature input modules, Model(s): [Q64TD](#), [Q64TD-F10](#), [Q68TD-G](#), [Q68TD-G-H01](#), [Q68TD-G-H02](#)

Melsec-Q Series tracking cables, Model(s): [QC10TR](#), [QC30TR](#)

Melsec-Q Series WEB server modules, Model(s): [QJ71WS96](#)

Melsec-QS Series base units, Model(s): [QS034B](#), [QS034B-E](#), [QS034B-K](#)

Melsec-QS Series CC-link IE field network master/local modules, Model(s): [QS0J71GF11-T2](#)

Melsec-QS Series CC-link master modules, Model(s): [QS0J61BT12](#), [QS0J61BT12-K](#)

Melsec-QS Series CC-link remote I/O modules, Model(s): [QS0J65BTB2-12DT](#), [QS0J65BTB2-12DT-K](#), [QS0J65BTS2-4T](#), [QS0J65BTS2-8D](#)

Melsec-QS Series CPU modules, Model(s): [QS001CPU](#), [QS001CPU-K](#)

Melsec-QS Series extension cables for relay modules, Model(s): [QS90CBL-SE01](#), [QS90CBL-SE15](#)

Melsec-QS Series power supplies, Model(s): [QS061P-A1](#), [QS061P-A1-K](#), [QS061P-A2](#), [QS061P-A2-K](#)

Melsec-QS Series relay modules, Model(s): [QS90SR2SN-CC](#), [QS90SR2SN-EX](#), [QS90SR2SN-Q](#), [QS90SR2SP-CC](#), [QS90SR2SP-EX](#), [QS90SR2SP-Q](#)

MELSECWinCPU Module, "MELSEC iQ-R Series", Model(s): [R102WCPU-W](#)

Melsec-WS Series CC-link network interface modules, Model(s): [WS0-GCC100202](#)

Motion Control Board, Model(s): [MR-EM441G](#), [MR-EM441G-Snn](#)

Motion controller system base units, Model(s): [A168B](#), [A172B](#), [A175B](#), [A178B](#), [A178B-S1](#), [A178B-S2](#), [A178B-S3](#), [A255B](#), [A268B](#), [A272B](#), [A275B](#), [A278B](#)

Motion controller system CPU modules, Model(s): [A171SCPU](#), [A171SCPU-S3](#), [A171SHCPU](#), [A171SHCPUN](#), [A172SHCPU](#), [A172SHCPUN](#), [A172SHCPUN-S5](#), [A173UHCPU](#), [A173UHCPU-S1](#), [A273UHCPU](#), [A273UHCPU-S3](#)

Motion controller system manual pulse generators/synchronous encoder modules, Model(s): [A171SENC](#), [A172SENC](#), [A273EX](#)

Motion controller system servo external modules, Model(s): [A278LX](#)

Motion controller system synchronous encoders, Model(s): [MR-HENC](#)

OPC UA Communication Module, "MELSEC iQ-F", Model(s): [FX5-OPC](#)

Open type, Programmable controllers, Model(s): [Base R65B](#) and [RQ65B](#), [CC-Link System Master/Local RJ61BT11](#), [CPU Model Q26UDVCPU-Fnn](#), [FCU7-MA032](#), [FCU7-MA032-S01](#), [FCU7-MU032](#), [FCU7-MU032-S01](#), [FCU7-MU525](#), [FX5](#), followed by -C1PS, followed by -5V, [NZ1BLC](#), [NZ2EX2S1-16D](#), [NZ2EX2S1-16T](#), [NZ2EX2S1-16TE](#), [NZ2FTAS-60AD4](#), [NZ2FT-C24](#), [NZ2FT-CN](#), [NZ2FT-DN](#), [NZ2FT-EC](#), [NZ2FT-EIP](#), [NZ2FT-EIP](#), [NZ2FT-MT](#), [NZ2FT-PBV](#), [NZ2FTPD1](#), [NZ2FTPDO](#), [NZ2FT-PN](#), [NZ2FTS1-16D](#), [NZ2FTS1-16DE](#), [NZ2FTS1-16T](#), [NZ2FTS1-16TE](#), [NZ2FTS2-4A](#), [NZ2FTS2-8T](#), [NZ2FTS2-8TE](#), [NZ2FTS3-4R](#), [NZ2FTS3-8D](#), [NZ2FTS3-8DE](#), [NZ2FTS4-4D](#), [NZ2FTS4-4DE](#), [NZ2FTS4-4T](#), [NZ2FTS4-4TE](#), [NZ2FTS4-4TE1](#), [NZ2FTS-60AD4](#), [NZ2FTS-60DA4](#), [NZ2FTS-60RD4](#), [NZ2FTS-60TD4](#), [NZ2FTS-D62P2](#), [NZ2FTS-D62P2](#), [NZ2FTS-D66D1](#), [NZ2GF2B2-16A](#), [NZ2GF2B2-16R](#), [NZ2GF2B2-16S](#), [NZ2GF2S1-16D](#), [NZ2GF2S1-16T](#), [NZ2GF2S1-16TE](#), [NZ2GF2S2-16A](#), [NZ2GF2S2-16S](#), [NZ2GFCE3-32D](#), [NZ2GFCE3-32DT](#), [NZ2GFCE3-32T](#), [NZ2GFCE3N-32D](#), [NZ2GFCE3N-32DT](#), [NZ2GFCE3N-32T](#), [NZ2MFB1-32D](#), [NZ2MFB1-32DT](#), [NZ2MFB1-32DTE1](#), [NZ2MFB1-32T](#), [NZ2MFB1-32TE1](#), [NZ2MFB2-16A](#), [NZ2MFB2-16R](#), [QA1S6ADP](#), [QA1S6ADP-S1](#), [RD81OPC96](#), [Z2GF2S2-16R](#)

Open type, Programmable controllers, Model(s): [Accessory](#), [Space unit](#), Model [LG69](#), [LG69-CM](#)

Open type, Programmable controllers, Model(s): [Energy Saving Data Collecting Server](#), [EcoServerIII](#), [MES3-255C-DM](#)

Open type, Programmable controllers, Model(s): [Energy Saving Data Collecting Server](#), [EcoWebServerIII](#), [MES3-255C-DM-CN](#) and [MES3-255C-DM-EN](#)

Open type, Programmable controllers, Model(s): [FX3GA](#) -, followed by 24MR, 40MR, 60MR, 24MT, 40MT or 60MT, followed by -CM

Open type, Programmable controllers, Model(s): [FX3GE](#) -, followed by 24MR, 40MR, 24MT or 40MT, followed by /ES, /ESS, /DS, or /DSS suffix.

Open type, Programmable controllers, Model(s): [FX3S](#) -, followed by 10MT, 14MT, 20MT, 30MT, 10MR, 14MR, 20MR, 30MR followed by /ES or /ESS or /DS or /DSS suffix, may be followed by -2AD, may be followed by -A

Open type, Programmable controllers, Model(s): [FX5S](#) -, followed by 30MR, 30MT, 40MR, 40MT, 60MR, 60MT, 80MR, 80MT followed by /ES or /ESS, may be followed by -A suffix.

Open type, Programmable controllers, Model(s): [NZ2GF2B-60AD4](#), [NZ2GF2BN-60AD4](#), [NZ2EX2B-60AD4](#)

Open type, Programmable controllers, Model(s): [NZ2GF2B-60DA4](#), [NZ2GF2BN-60DA4](#), [NZ2EX2B-60DA4](#)

Open type, Programmable controllers, Model(s): [NZ2GFSS2-32D](#), [NZ2EXSS2-8TE](#), [NZ2EXSS2-8TE-K](#)

Open type, Programmable controllers, Model(s): [Q172DSCPU-Sn](#) (where "n" is an optional numerical suffix signifying changes in software) and [Q173DSCPU-Sn](#)

Open type, Programmable controllers, Model(s): [Q24DHCCPU-VG-Bnnn](#), (Bundle Variant three character alphanumeric suffix)

Open type, Programmable controllers, Model(s): [RH42C4NT2P](#), [RY40PT5P](#), [RY41PT1P](#) and [RY42PT1P](#)

Open type, Programmable controllers, Model(s): [Serial Communication RJ71C24-R2](#) - followed by 4AD-PT-ADP, 4AD-TC-ADP,

followed by additional numbers and/or letters.

Open type, Programmable controllers, Model(s): Serial Communication RJ71C24 - followed by 4AD-PT-ADP, 4AD-TC-ADP, followed by additional numbers and/or letters.

Open type, Programmable controllers, Model(s): Serial Communication RJ71C24-R4 - followed by 4AD-PT-ADP, 4AD-TC-ADP, followed by additional numbers and/or letters.

Open type, Programmable controllers, "AnS-Q Unit Conversion Adapter: Types", Model(s): A1SADP-Q, A1SADP-Q51B, A1SADP-Q52B

Open type, Programmable controllers, "FCU7", Model(s): FCU7-DA636-21, FCU7-DA636-23, FCU7-DA636-33, FCU7-DA636-73, FCU7-DA636X-02, FCU7-MU527, FCU7-MU528

Open type, Programmable controllers, "FX5 Series", Model(s): FX5-1PSU-5V, FX5-CNV-IF

Open type, Programmable controllers, "FX5 Series", Model(s): FX5 - followed by 4AD-PT-ADP, 4AD-TC-ADP, followed by additional numbers and/or letters.

Open type, Programmable controllers, "FX5 Series", Model(s): FX5- , followed by 32ER, 32ET followed by /ES, /ESS, /DS or /DSS.

Open type, Programmable controllers, "FX5 Series", Model(s): FX5- followed by 4AD-ADP, 4DA-ADP, 4A-ADP, followed by additional numbers and/or letters.

Open type, Programmable controllers, "FX5 Series", Model(s): FX5U- , followed by 32MR, 32MT , 64MR, 64MT, 80MR, 80MT, followed by /ES, /ESS, /DS or /DSS, may be followed by -A, may be followed by additional alphanumeric suffixes.

Open type, Programmable controllers, "FX5 Series", Model(s): FX5UC- followed by 32MT, 32MR, 64MT or 96MT, followed by /D, /DS or /DSS, may be followed by -TS, may be followed by additional alphanumeric suffixes

Open type, Programmable controllers, "FX5 Series", Model(s): Intelligent Function module, Model FX5 - followed by CCLIEF

Open type, Programmable controllers, "Graphic Operation Terminal", Model(s): GT2508F-VTNA, GT2508F-VTND, GT2508-VTBA-010, GT2510F-VTNA, GT2510F-VTND, GT2510-VTBA-010, GT2512F-STNA, GT2512F-STND, GT2512-STBA-010, GT2708-VTBA-010, GT2710-VTBA-010, GT2715-VTBA-010

Open type, Programmable controllers, "MELSEC CC-Link IE", Model(s): NZ2EX2S-D41A01, NZ2EX2S-D41D01, NZ2EX2S-D41P01, NZ2GF2B1-16DT, NZ2GFSS2-16DTE-S1, NZ2GFSS2-32D-S1, NZ2GFSS2-8D-S1, NZ2GFSS2-8TE-S1, NZ2GN2S-D41D01, NZ2GN2S-D41P01, NZ2GN2S-D41PD02, NZ2GN-GFB

Open type, Programmable controllers, "MELSEC CC-Link IE", Model(s): Field Network Remote Device A/D Conversion module NZ2GFCE-60ADI8

Open type, Programmable controllers, "MELSEC CC-Link IE", Model(s): Field Network Remote Device A/D Conversion module NZ2GFCE-60ADV8

Open type, Programmable controllers, "MELSEC CC-Link IE", Model(s): Field Network Remote Device D/A Conversion module NZ2GFCE-60DAI8

Open type, Programmable controllers, "MELSEC CC-Link IE", Model(s): Field Network Remote Device D/A Conversion module NZ2GFCE-60DAV8

Open type, Programmable controllers, "MELSEC CC-Link IE", Model(s): Field Network Remote I/O Module NZ2GF2B1-32DTE

Open type, Programmable controllers, "MELSEC CC-Link IE", Model(s): Field Network Remote I/O Module NZ2GF2B1-32D

Open type, Programmable controllers, "MELSEC CC-Link IE", Model(s): Field Network Remote I/O Module NZ2GF2B1-32DT

Open type, Programmable controllers, "MELSEC CC-Link IE", Model(s): [Field Network Remote I/O Module NZ2GF2B1-32T](#)

Open type, Programmable controllers, "MELSEC CC-Link IE", Model(s): [Field Network Remote I/O Module NZ2GF2B1-32TE](#)

Open type, Programmable Controllers, "MELSEC CC-Link IE", Model(s): [NZ2GFSS2-16DTE-S1-K](#), [NZ2GFSS2-32D-S1-K](#), [NZ2GFSS2-8D-S1-K](#), [NZ2GFSS2-8TE-S1-K](#)

Open type, Programmable controllers, "MELSEC iQ-F", Model(s): [Analog Output Module, FX5-4DA](#), [CC-Link Master Slave Module FX5-CCL-MS](#), [FX5-CCLGN-MS](#)

Open type, Programmable controllers, "MELSEC iQ-R", Model(s): [CANopen RJ71CN91](#), [Device Net Master-Slave RJ71DN91](#), [Ethernet/IP Network Interface RJ71EIP91](#), [I/O RY18R2A](#), [PROFIBUS-DP RJ71PB91V](#), [R04CPU](#), [R08/16/32/120PSFCPU](#), [R08/16/32/120SFCPU](#), [R08/16/32/120SFCPU-K](#), [R08CPU](#), [R08PCPU](#), [R120CPU](#), [R120PCPU](#), [R04/08/16/32/120ENCPU](#), [R12CCPU-V](#), [R12CCPU-V-Bnnn](#), [R12CCPU-V-Fnn](#), [R16CPU](#), [R16PCPU](#), [R32CPU](#), [R32PCPU](#), [R60AD16-G](#), [R60AD4](#), [R60AD8-G](#), [R60ADH4](#), [R60ADI8](#), [R60ADV8](#), [R60DA16-G](#), [R60DA4](#), [R60DA8-G](#), [R60DAH4](#), [R60DAI8](#), [R60DAV8](#), [R60RD8-G](#), [R60TCRT4](#), [R60TCRT4BW](#), [R60TCRT4-TS](#), [R60TCTRT2TT2](#), [R60TCTRT2TT2BW](#), [R60TCTRT2TT2-TS](#), [R60TD8-G](#), [R610B-HT](#), [R612B](#), [R61P](#), [R62P](#), [R63P](#), [R63P-H10](#), [R63RP](#), [R64P](#) and [R64RP](#) may be followed by [\(C\)](#), [R68B](#), [R69P](#), [R69RP](#), [R6PSFM](#), [R6SFM](#), [R6SFM-K](#), [RD55UP06-V](#), [RD55UP06-V-Bnnn](#), [RD55UP12-V](#), [RD55UP12-V-Bnnn](#), [RD62D2](#), [RD62P2](#), [RD62P2E](#), [RD75D2](#), [RD75D4](#), [RD75P2](#), [RD75P4](#), [RD81DC96](#), [RD81DL96](#), [RD81MES96](#), [RJ71EC93](#), [RJ71EN71](#), [RJ71GF11-T2](#), [RJ71GP21-SX](#), [RJ72GF15-T2](#), [RQ612B](#), [RQ68B](#), [RX10](#), [RX10-TS](#), [RX28](#), [RX40C7](#), [RX40C7-TS](#), [RX40NC6B](#), [RX40NC6H](#), [RX40PC6H](#), [RX41C4](#), [RX41C4-TS](#), [RX41C6HS](#), [RX42C4](#), [RX61C6HS](#), [RY10R2](#), [RY10R2-TS](#), [RY20S6](#), [RY40NT5P](#), [RY40NT5P-TS](#), [RY40PT5B](#), [RY40PT5P-TS](#), [RY41NT2P](#), [RY41NT2P-TS](#), [RY41PT1P-TS](#), [RY42NT2P](#), [Simple Motion Board, Model MR-EM340GF](#)

Open type, Programmable controllers, "MELSEC iQ-R", Model(s): [Ethernet/IP Network Interface RJ71EIP91-Fnn](#)

Open type, Programmable controllers, "MELSEC", Model(s): [L60RD8\(-CM\)](#), [LD40PD01\(-CM\)](#), [NZ2EX2B1N-16D](#), [-16T](#), [-16TE](#), [NZ2GF2B1N1-16D](#), [-16T](#), [-16TE](#)

Open type, Programmable controllers, "MELSEC", Model(s): [NZ2GFSS2-8D](#), [NZ2GFSS2-8TE](#), [NZ2GFSS2-16DTE](#)

Open type, Programmable controllers, "Melsec-L Series", Model(s): [Extension base unit models LA1S51B](#), [Extension base unit models LA1S65B](#), [Extension base unit models LA1S68B](#)

Open type, Programmable controllers, "Melsec-Q Series", Model(s): [MR-MC220U0](#), [MR-MC220U0-Snn](#), [MR-MC220U3](#), [MR-MC220U3-Snn](#), [MR-MC220U6](#), [MR-MC220U6-Snn](#), [MR-MC221M2U0](#), [MR-MC221M2U0-Snn](#), [MR-MC221M2U3](#), [MR-MC221M2U3-Snn](#), [MR-MC221M2U6](#), [MR-MC221M2U6-Snn](#), [NZ2GFCF1-32D](#), [-32DT](#), [-32T](#), [Q26DHCCPU-LS](#), [Q26DHCCPU-LS-Bnnn](#)

Open type, Programmable controllers, "Multi input (voltage/current/temperature) unit", Model(s): [L60MD4-G](#), [L60MD4-G-CM](#)

Open type, Programmable controllers, "UR20 u-remote", Model(s): [NZ2FTAS-60AD4](#), [NZ2FT-C24](#), [NZ2FT-CN](#), [NZ2FT-DN](#), [NZ2FTS1-16D](#), [NZ2FTS1-16T](#), [NZ2FTS2-4A](#), [NZ2FTS2-8T](#), [NZ2FTS2-8TE](#), [NZ2FTS3-8D](#), [NZ2FTS4-4D](#), [NZ2FTS4-4T](#), [NZ2FTS-D66D1](#)

Open type, Programmable controllers, Bus Conversion Adapter, "FX5 Series", Model(s): [FX5-CNV-BUSC](#) may be followed by additional alphanumeric suffix

Open type, Programmable controllers, Camera Recorder Module, "MELSEC iQ-R", Model(s): [RD81RC96-CA](#)

Open type, Programmable controllers, CC-Link IE TSN Remote I/O module, Model(s): [NZ2GN2B1-32D](#), [NZ2GN2B1-32DT](#), [NZ2GN2B1-32DTE](#), [NZ2GN2B1-32T](#), [NZ2GN2B1-32TE](#), [NZ2GN2S1-32D](#), [NZ2GN2S1-32DT](#), [NZ2GN2S1-32DTE](#), [NZ2GN2S1-32T](#), [NZ2GN2S1-32TE](#)

Open type, Programmable controllers, CC-Link IE TSN Remote I/O module, "MELSEC Series", Model(s): [NZ2GN2B1-16D](#), [NZ2GN2B1-16T](#), [NZ2GN2B1-16TE](#), [NZ2GN2S1-16D](#), [NZ2GN2S1-16T](#), [NZ2GN2S1-16TE](#), [NZ2GNCE3-32D](#), [NZ2GNCE3-32DT](#), [NZ2GNCF1-32D](#), [NZ2GNCF1-32T](#), [NZ2GNSS2-16DTE](#), [NZ2GNSS2-8D](#), [NZ2GNSS2-8TE](#)

Open type, Programmable controllers, I/O Extension units, "FX5 Series", Model(s): [FX5-C16EYR/D-TS](#) followed by /D or /

DS(C32EX) or /DSS(C32EYT,C32ET) suffix, may be followed by TS, may be followed by additional alphanumeric suffix

Open type, Programmable controllers, I/O Extension units, "FX5 Series", Model(s): [FX5-C32ET](#) followed by /D or /DS(C32EX) or /DSS(C32EYT,C32ET) suffix, may be followed by TS, may be followed by additional alphanumeric suffix

Open type, Programmable controllers, I/O Extension units, "FX5 Series", Model(s): [FX5-C32EX](#) followed by /D or /DS(C32EX) or /DSS(C32EYT,C32ET) suffix, may be followed by TS, may be followed by additional alphanumeric suffix

Open type, Programmable controllers, I/O Extension units, "FX5 Series", Model(s): [FX5-C32EYT](#) followed by /D or /DS(C32EX) or /DSS(C32EYT,C32ET) suffix, may be followed by TS, may be followed by additional alphanumeric suffix

Open type, Programmable controllers, MES Module, Model(s): [QJ71MES96N](#)

Open type, Programmable controllers, positioning modules, "MELSEC iQ-R", Model(s): [RD77GF16](#), [RD77GF16-APnnn](#), [RD77GF4](#), [RD77GF8](#)

Open type, Programmable controllers, Recorder Module, "MELSEC iQ-R", Model(s): [RD81RC96](#)

Open-type, PLC Interface, Model(s): [FX3U-128ASL-M](#), [FX5-ASL-M](#)

Open-type, Programmable Controllers, Temperature Control Module, Model(s): [FX5-4LC](#)

Panel mount - Programmable controllers, "Graphic Operation Terminal", Model(s): [GS2110-WTBD](#), [GS2110-WTBD****](#), [GS2110-WTBD-N](#)

Panel Mount - Programmable controllers, "Graphic Operation Terminal", Model(s): [GT2508-VTBA](#), [GT2508-VTBA-040](#), [GT2508-VTBD](#), [GT2508-VTBD-040](#), [GT2508-VTWA](#), [GT2508-VTWD](#), [GT2510-VTBA](#), [GT2510-VTBA-040](#), [GT2510-VTBD](#), [GT2510-VTBD-040](#), [GT2510-VTWA](#), [GT2510-VTWD](#), [GT2512-STBA](#), [GT2512-STBA-040](#), [GT2512-STBD](#), [GT2512-STBD-040](#), [GT2512-STWA](#), [GT2512-STWD](#), [GT2705-VTBD-040](#), [GT2708-STBA-040](#), [GT2708-STBD-040](#), [GT2708-VTBA-040](#), [GT2708-VTBD-040](#), [GT2710-STBA-040](#), [GT2710-STBD-040](#), [GT2710-VTBA-040](#), [GT2710-VTBD-040](#), [GT2712-STBA-040](#), [GT2712-STBD-040](#), [GT2712-STWD](#), [GT2715-VTBA](#), [GT2715-VTBA-040](#), [GT2715-VTBD](#), [GT2715-VTBD-040](#)

PCMCIA cards, "Melsec-Q Series", Model(s): [A30CD-PCF](#)

PLC interfaces, Model(s): [LJ51AW12AL](#), [LJ51AW12D2](#), [QJ51AW12AL](#), [QJ51AW12AL\(C\)](#), [QJ51AW12D2](#), [QJ51AW12D2](#), [RJ51AW12AL](#)

Position boards, Model(s): [MR-MC210](#), [MR-MC211](#), [MR-MC211M2 -Snn](#), [MR-MC211-Snn](#), [MR-MC221](#), [MR-MC221M2](#), [MR-MC221M2-Snn](#), [MR-MC240](#), [MR-MC240-Snn](#), [MR-MC241](#), [MR-MC241-Snn](#)

Position Boards, Model(s): [MR-MC210-Snn](#)

Positioning modules units, "Melsec-L Series", Model(s): [LD77MH16](#), [LD77MH4](#), [LD77MS16](#), [LD77MS2](#), [LD77MS4](#)

Power supply modules, Model(s): [Q64RPN](#)

Power Supply Modules, Model(s): [Q63P](#), [Q63P-FAM](#), [Q63RP](#)

Power Supply Units, Model(s): [L63SP](#), [L63SP-CM](#)

Printer interface modules, Model(s): [GT15-PRN](#)

Profibus Series interface master modules, Model(s): [AISJ71PB92D](#), [AISJ71PB96F](#), [AJ71PB92D](#), [AJ71PB96F](#)

Profinet I/O controller, Model(s): [RJ71PN92](#)

PROFINET IO Device, "MELSEC iQ-R", Model(s): [RJ71PN93](#)

Programmable controllers, Model(s): [A8GT-70GOT-EB](#), [A8GT-70GOT-EW](#), [A8GT-70GOT-SB](#), [A8GT-70GOT-SW](#), [A8GT-70GOT-TB](#),

A8GT-70GOT-TW, A8GT-J61BT13, A8GT-J61BT15, A8GT-PWEL, A8GT-PW-EU, A8GT-PWST, A8GT-PWTF, A950GOT-LBD, A950GOT-LBD-M3, A950GOT-SBD, A950GOT-SBD-M3, A950GOT-TBD, A950GOT-TBD-M3, A951GOT-LBD, A951GOT-LBD-M3, A951GOT-QLBD, A951GOT-QLBD-M3, A951GOT-QSBD, A951GOT-QSBD-M3, A951GOT-SBD, A951GOT-SBD-M3, A951GOT-TBD, A951GOT-TBD-M3, A953GOT-LBD, A953GOT-LBD-M3, A953GOT-SBD, A953GOT-SBD-M3, A953GOT-TBD, A953GOT-TBD-M3, A956GOT-LBD, A956GOT-LBD-M3, A956GOT-SBD, A956GOT-SBD-M3, A956GOT-TBD, A956GOT-TBD-M3, A956WGOT-TBD, A960GOT-EBA, A960GOT-EBA-EU, A960GOT-EBD, A970GOT-LBA, A970GOT-LBA-EU, A970GOT-LBD, A970GOT-SBA, A970GOT-SBA-EU, A970GOT-SBD, A970GOT-TBA, A970GOT-TBA-B, A970GOT-TBA-BW, A970GOT-TBA-CH, A970GOT-TBA-EU, A970GOT-TBD, A970GOT-TBD-B, A970GOT-TBD-BW, A970GOT-TBD-CH, A975GOT-TBA, A975GOT-TBA-B, A975GOT-TBA-BW, A975GOT-TBA-CH, A975GOT-TBA-EU, A975GOT-TBD, A975GOT-TBD-B, A975GOT-TBD-BW, A975GOT-TBD-CH, A985GOT-TB4, A985GOT-TBA, A985GOT-TBA-EU, A985GOT-TBA-V, A985GOT-TBA-V-EU, A985GOT-TBD, A985GOT-TBD-V, A985GOT-TBD-V-EU, A9GT-50WBUSS, A9GT-50WQBUSS, A9GT-50WRS2, A9GT-50WRS4, A9GT-70KBF, A9GT-80R1, A9GT-80V4, A9GT-80V4R1, A9GT-BUS2S, A9GT-BUS2SU, A9GT-BUSS, A9GT-BUSS0, A9GT-BUSSU, A9GT-FNB, A9GT-FNB12M, A9GT-FNB1M, A9GT-FNB2M, A9GT-FNB4M, A9GT-FNB8M, A9GT-J71E71-T, A9GT-Q71BR13, A9GT-QBUS2S, A9GT-QBUS2SU, A9GT-QBUSS, A9GT-QCNB, A9GT-QFNB, A9GT-QFNB12M, A9GT-QFNB1M, A9GT-QFNB2M, A9GT-QFNB4M, A9GT-QFNB8M, A9GT-QJ71LP23, A9GT-RS2, A9GT-RS2T, A9GT-RS4, AJ65FBTA2-16T-Sn*, F1-12MR-UL, F1-20MR-UL, F1-30MR-UL, F1-40MR-UL, F1-60MR-UL, F-20MR-UL, F2-40MR-UL, F2-60MR-UL, F-40MR-UL, FCU7-DU180-11, FCU7-DU180-1S, FCU7-MU526, FX3GC-32MT-/D, FX3GC-32MT-/DSS, GT2705-VTBD-110, GT2710-VTWA-130, GT2710-VTWD-130, GT2715-VTWA-130, MR-MC211M2, MR-MC211M2-Snn, QE81DM

Programmable controllers, Model(s): FX3SA followed by 10MT, 14MT, 20MT, 30MT, 10MR, 14MR, 20MR, 30MR followed by -CM.

Programmable controllers, Model(s): GT2506HS-VTBD** where * is optional and may be 0 to 9 incl., A to Z incl

Programmable Controllers, Model(s): GT27-R2, GT27-ROUT, GT25-FNADP, L04HCPU, L08HCPU, L16HCPU, L32HCPU, Listed Accessory Units GT25-J71GN13-T2, MI5122 may be followed by (C), NZ2AW1C2D2, NZ2AW1GNAL, NZ2AW1GNAL(C), NZ2FT-BT, NZ2FT-GN, NZ2FTS-60IOLN4, NZ2GF2S-60IOLD8, NZ2GN2B-60AD4, NZ2GN2B-60DA4, NZ2GN2S-60AD4, NZ2GN2S-60DA4, NZ2MF2S1-32D, NZ2MF2S1-32DT, NZ2MF2S1-32DTE1, NZ2MF2S1-32T, NZ2MF2S1-32TE1, R60ADI8-HA, R60MH112, R60MH112(c), R60MH112NA, R60MH112NA(c), R64P, R64RP, RD60P8-G, RD81MES96N, RJ51AW12AL(C), RJ51AW12AL2, RJ71GN11-T2, RJ71GP21S-SX, RX40NC6S-TS may be followed by "(C)", RX70C4, RX71C4, RX72C4, RY48PT20S-TS

Programmable Controllers, Model(s): FX5UJ-24MR followed by /ES or /ESS, may be followed by -A, may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-24MR/DS may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-24MT followed by /ES or /ESS, may be followed by -A, may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-24MT/DS may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-24MT/DSS may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-40MR followed by /ES or /ESS, may be followed by -A, may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-40MR/DS may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-40MT followed by /ES or /ESS, may be followed by -A, may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-40MT/DS may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-40MT/DSS may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-60MR followed by /ES or /ESS, may be followed by -A, may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-60MR/DS may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-60MT followed by /ES or /ESS, may be followed by -A, may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-60MT/DS may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): FX5UJ-60MT/DSS may be followed by additional alphanumeric suffixes.

Programmable Controllers, Model(s): GT2505HS-VTBD where * is optional and may be 0 to 9 incl., A to Z incl.

Programmable Controllers, Model(s): GT2505HS-VTBD** where * is optional and may be 0 to 9 incl., A to Z incl.

Programmable Controllers, Model(s): GT2505HS-VTBD01 where * is optional and may be 0 to 9 incl., A to Z incl.

Programmable Controllers, Model(s): GT2505HS-VTBD05 where * is optional and may be 0 to 9 incl., A to Z incl.

Programmable Controllers, Model(s): GT2505HS-VTBD06 where * is optional and may be 0 to 9 incl., A to Z incl.

Programmable Controllers, Model(s): GT2505HS-VTBD07 where * is optional and may be 0 to 9 incl., A to Z incl.

Programmable Controllers, Model(s): GT2507T-WT*D-*** Where * is optional and may be 0 to 9 incl., A to Z incl.

Programmable Controllers, Model(s): MELIPC CPU Module, Model MI5113GFCPU-VW may be followed by (C)

Programmable Controllers, Model(s): MELIPC Fan Module, Accessory Model(s) MI5FAN may be followed by (C)

Programmable Controllers, Model(s): MELIPC Power Supply Module, Model MI5A1P may be followed by (C)

Programmable Controllers, Model(s): Model GT2104 followed by P, followed by M, followed by B, followed by either D or L, may be followed by nothing or S or S2, may be followed by * where * is optional and may be 0 to 9 inclusive, A to Z inclusive.

Programmable controllers, "FX5 Series", Model(s): FX5-16ER followed by /ES or /ESS, FX5-16EX followed by /ES or /ESS, FX5-16EYR followed by /ES or /ESS, FX5-16EYT followed by /ES or /ESS, FX5-8EX followed by /ES or /ESS, FX5-8EYR followed by /ES or /ESS, FX5-8EYT followed by /ES or /ESS

Programmable controllers, "FX5 Series", Model(s): FX5-16ET followed by /ES-H or ESS-H or /ES or /ESS

Programmable controllers, "Graphic Operation Terminal GOT SIMPLE Series", Model(s): GS2107-WTBD may be followed by ** where * is any alphanumeric or symbol suffix.

Programmable controllers, "Graphic Operation Terminal", Model(s): GT2105-Q**DS** where * is optional and may be 0 to 9 incl., A to Z incl.

Programmable Controllers, "Graphic Operation Terminal", Model(s): GS2512-WXTBD maybe followed by -***, where * is optional and may be 0 to 9 incl., A to Z incl.

Programmable Controllers, "Graphic Operation Terminal", Model(s): GT2512-WXT*D-*** where * is optional and may be 0 to 9 incl., A to Z incl.

Programmable Controllers, "MELSEC FX3 Series", Model(s): FX3U-16CCL-M may be followed by a suffix number 0 to 9, and/or a suffix letter A to Z. Suffix does not have the limitation number of digits

Programmable Controllers, "MELSEC FX3 Series", Model(s): FX3U-64CCL may be followed by a suffix number 0 to 9, and/or a suffix letter A to Z. Suffix does not have the limitation number of digits

Programmable Controllers, "MELSEC FX3UC Series", Model(s): FX3UC-32MT-LT-2

Programmable controllers, "MELSEC iQ-F", Model(s): Analog Input Module, FX5-4AD, FX5-8AD, FX5-2HC/ES, Positioning Module, FX5-20PG-P

Programmable Controllers, "MELSEC iQ-L Series", Model(s): [LD78G16](#), [LD78G4](#)

Programmable controllers, "MELSEC iQ-R", Model(s): [R00CPU](#), [R01CPU](#), [R02CPU](#), [RD77GF32](#), [RD78GHV](#), [RD78GHW](#), [RD78G-S1](#)

Programmable controllers, "MELSEC iQ-R", Model(s): [RD78Gn](#) (where n = 2, 4, 8, 16, 32 or 64).

Programmable Controllers, "MELSEC iQ-R", Model(s): [R310B-HT](#), [R310RB](#), [R312B](#), [R33B](#), [R35B](#), [R38B](#), [R38RB-HT](#), [R610RB](#), [R68RB-HT](#), [R6RFM](#), [RJ71BR11](#), [RJ71GN11-EIP](#), [RY41NT2H](#), [RY41PT2H](#)

Programmable Controllers, "Open", Model(s): [Ethernet Module FX5-ENET](#), [Ethernet module FX5-ENET/IP](#), [PROFIBUS-DP Master Module FX5-DP-M](#)

Programmable Controllers, "Open", Positioning module, "Open", Model(s): [FX5-20PG-D](#)

Programmable controllers, Fast Responsivity High Speed Analog-Digital Converter Module, "MELSEC iQ-R Series", Model(s): [R60ADH3FR](#)

Programmable controllers, GP-IB Interface Module, "MELSEC iQ-R Series", Model(s): [RJ71GB91](#)

Programmable Controllers, Position Board, Model(s): [MR-MC341](#)

Programmable logic controllers, industrial control terminals, Model(s): [JAC2001.4](#), [VN-JPC201A](#), [VN-JPC201B](#), [VN-JPC201C](#)

QnAs Series CPU base units, Model(s): [A1S38HB](#)

QnAs Series CPU modules, Model(s): [Q2ASCPU](#), [Q2ASCPU-S1](#), [Q2ASHCPU](#), [Q2ASHCPU-S1](#)

QnAs Series ethernet modules, Model(s): [A1SJ71QE71-B2](#), [A1SJ71QE71-B5](#), [A1SJ71QE71N3-T](#), [A1SJ71QE71N-B2](#), [A1SJ71QE71N-B5](#), [A1SJ71QE71N-B5T](#), [A1SJ71QE71N-T](#), [AJ71E71N-T](#), [AJ71QE71N-T](#)

QnAs Series input modules, Model(s): [A1S42Y](#), [A1SH42](#), [A1SX810](#), [A1SX820](#), [A1SX840](#), [A1SX840-S1](#), [A1SX840-S2](#), [A1SX841](#), [A1SX841-S2](#), [A1SX842](#), [A1SX848Y18](#), [A1SX848Y5](#), [A1SX871](#), [A1SX880](#), [A1SX880-S1](#), [A1SX880-S2](#), [A1SX881](#), [A1SX881-S2](#)

QnAs Series network modules, Model(s): [A1SJ71QBR11](#), [A1SJ71QLP21](#), [A1SJ71QLP21GE](#), [A1SJ71QLP21S](#), [A1SJ71QLR21](#), [A1SJ72QBR15](#), [A1SJ72QLP25](#), [A1SJ72QLR25](#)

QnAs Series power supply modules, Model(s): [A1S61P](#)

QnAs Series serial communication modules, Model(s): [A1SJ71QC24](#), [A1SJ71QC24N](#), [A1SJ71QC24N1](#), [A1SJ71QC24N1-R2](#), [A1SJ71QC24N-R2](#), [A1SJ71QC24-R2](#)

Remote I/O modules, Model(s): [AF65BTB2-16DT](#), [AJ55TB32-16DR](#), [AJ55TB32-16DT](#), [AJ55TB32-4DR](#), [AJ55TB32-4DT](#), [AJ55TB32-8DR](#), [AJ55TB32-8DT](#), [AJ65BTB1-16DT](#), [AJ65BTB2-16DR](#), [AJ65DBTB1-32DR](#), [AJ65DBTB1-32DT1](#), [AJ65EBTB3-16DT](#), [AJ65MBTC1-32DT-DS1](#), [AJ65MBTC1-32DT-DS2](#), [AJ65MBTC1-56DT-DS1](#), [AJ65MBTC1-56DT-DS2](#), [AJ65MBTCD1-32DT-HAM](#), [AJ65MBTL1N-16DT](#), [AJ65SBTB1-16DT](#), [AJ65SBTB1-16DT1](#), [AJ65SBTB1-16DT2](#), [AJ65SBTB1-16DT3](#), [AJ65SBTB1-32DT](#), [AJ65SBTB1-32DT1](#), [AJ65SBTB1-32DT2](#), [AJ65SBTB1-32DT3](#), [AJ65SBTB1-32DTE1](#), [AJ65SBTB1-32KDT2](#), [AJ65SBTB1-32KDT8](#), [AJ65SBTB32-16DR](#), [AJ65SBTB32-16DT](#), [AJ65SBTB32-16DT2](#), [AJ65SBTB32-16KDR](#), [AJ65SBTB32-16KDT2](#), [AJ65SBTB32-16KDT8](#), [AJ65SBTB32-8DT](#), [AJ65SBTB32-8DT2](#), [AJ65SBTB32-QBDA16DT](#), [AJ65SBTC1-32DT](#), [AJ65SBTC1-32DT1](#), [AJ65SBTC1-32DT2](#), [AJ65SBTC1-32DT3](#), [AJ65SBTC4-16DT](#), [AJ65SBTC4-16DT2](#), [AJ65SBTCF1-32DT](#), [AJ65SBTW2-8TE-S3](#), [AJ65SBTW4-16DT](#), [AJ65VBTC32-16DT](#), [AJ65VBTC32-32DT](#), [AJ65VBTCF1-32DT1](#), [AJ65VBTCF1-32DT1](#), [AJ65VBTS32-16DT](#), [AJ65VBTS32-32DT](#), [FCU6-DX561](#)

Remote input modules, Model(s): [AJ35TB1-16D](#), [AJ35TB1-16T](#), [AJ55TB3-16D](#), [AJ55TB3-4D](#), [AJ55TB3-8D](#), [AJ65ABTP3-16D](#), [AJ65ABTP3-16DE](#), [AJ65BTB1-16D](#), [AJ65BTB2-16D](#), [AJ65BTC1-32D](#), [AJ65DBTB1-32D](#), [AJ65EBTB32-16D](#), [AJ65EBTB32-32D](#), [AJ65FBTA4-16D](#), [AJ65FBTA4-16DE](#), [AJ65MBTCD1-32D-HAM](#), [AJ65MBTL1N-16D](#), [AJ65MBTL1N-32D](#), [AJ65SBTB1-16D](#), [AJ65SBTB1-16D1](#), [AJ65SBTB1-16D-S7](#), [AJ65SBTB1-32D](#), [AJ65SBTB1-32D1](#), [AJ65SBTB1-32D5](#), [AJ65SBTB1-32KD](#), [AJ65SBTB1-8D](#), [AJ65SBTB2-16A](#), [AJ65SBTB2--16AG0](#), [AJ65SBTB2-16S](#), [AJ65SBTB2-8A](#), [AJ65SBTB2-8S](#), [AJ65SBTB2-8T](#), [AJ65SBTB2N-16A](#), [AJ65SBTB2N-32DT](#), [AJ65SBTB2N-32T](#), [AJ65SBTB2N-8A](#), [AJ65SBTB3-16A](#), [AJ65SBTB3-16D](#), [AJ65SBTB3-16D5](#), [AJ65SBTB3-16KD](#)

AJ65SBTB3-8D, AJ65SBTC1-16D, AJ65SBTC1-32D, AJ65SBTC1-32D1, AJ65SBTC4-16D, AJ65SBTC4-16DE, AJ65SBTC4-16DN, AJ65SBTCF1-32D, AJ65SBTW2-16T-S3, AJ65SBTW4-16D, AJ65VBTC3-16D, AJ65VBTC3-16DE, AJ65VBTC3-16TE, AJ65VBTC3-32D, AJ65VBTC3-32DE, AJ65VBTC3-32DE, AJ65VBTC3-32DE, AJ65VBTC3-8D, AJ65VBTCU3-16D1, AJ65VBTCU3-8D1, AJ65VBTS3-16D, AJ65VBTS3-32D

Remote input modules, Model(s): AJ65SBTB1-8T

Remote output modules, Model(s): AJ55TB2-16R, AJ55TB2-16T, AJ55TB2-4R, AJ55TB2-4T, AJ55TB2-8R, AJ55TB2-8T, AJ65BTB1-16T, AJ65BTB1D-32DR, AJ65BTB2-16R, AJ65BTB2-16T, AJ65BTC1-32T, AJ65DBTB1-32R, AJ65DBTB1-32T1, AJ65FBTA2-16T, AJ65FBTA2-16TE, AJ65FBTBA4-16D, AJ65FBTBA4-16DE, AJ65MBTL1N-16T, AJ65MBTL1N-32T, AJ65SBTB1-16T, AJ65SBTB1-16T1, AJ65SBTB1-16T1-S7, AJ65SBTB1-16TE, AJ65SBTB1-32T, AJ65SBTB1-32T1, AJ65SBTB1-32TE1, AJ65SBTB1-8T1, AJ65SBTB1-8TE, AJ65SBTB1B-16TE1, AJ65SBTB2-16R, AJ65SBTB2-16T, AJ65SBTB2-16T1, AJ65SBTB2-8R, AJ65SBTB2-8T1, AJ65SBTB2N-16R, AJ65SBTB2N-16S, AJ65SBTB2N-8R, AJ65SBTB2N-8S, AJ65SBTC1-32T, AJ65SBTC1-32T1, AJ65SBTCF1-32T, AJ65SBTCM1P-16T, AJ65VBTC2-16T, AJ65VBTC2-32T, AJ65VBTC2-8T, AJ65VBTCU2-16T, AJ65VBTCU2-8T, AJ65VBTS2-16T, AJ65VBTS2-32T

Serial multi-drop connection units, Model(s): GT01-RS4-M

Slave I/O modules, Model(s): AJ95FPBA42-16DTE, AJ95TB32-16DT

Slave input modules, Model(s): AJ95FPBA4-16DE, AJ95TB3-16D

Slave output modules, Model(s): AJ95FPBA2-16TE, AJ95TB2-16T

Special function modules, Model(s): AJ65BT-64AD, AJ65BT-64RD3, AJ65BT-64RD4, AJ65BT-68TD, AJ65BT-6DAI, AJ65BT-6DAV, AJ65BT-D62, AJ65BT-D62D, AJ65BT-D62D-S1, AJ65BT-D62-F10, AJ65BT-D75G4, AJ65BT-D75G4-S3, AJ65BT-D75P2-S3, AJ65BT-D75R2, AJ65BT-D75R2N, AJ65BT-RPI-10A, AJ65BT-RPI-10B, AJ65BTS-RPH, AJ65FBTA-RPH, AJ65MBTCD1-624ADA-HAM, AJ65SBT2B-64AD, AJ65SBT2B-64DA, AJ65SBT2B-64RD3, AJ65SBT2B-64TD, AJ65SBT-62DA, AJ65SBT-64AD, AJ65SBTB1-64D, AJ65SBTB1-64D1, AJ65SBTB1-64DT, AJ65SBTB1-64DT1, AJ65SBT-CLB, AJ65SBT-RPG, AJ65SBT-RPS, AJ65SBT-RPT, AJ65VBTCU-68ADI, AJ65VBTCU-68ADIN, AJ65VBTCU-68ADV, AJ65VBTCU-68ADV, AJ65VBTCU-68ADV-S1, AJ65VBTCU-68DAV, AJ65VBTCU-68DAVN, AJ65VBTCU-68DAV-S1, RY40PT5B-AS

SSCNETIII/H head units, Model(s): LJ72MS15, LJ72MS15-CM

ST Series analog-digital converter modules, Model(s): ST1AD2-I, ST1AD2-V, ST1DA1-I-F01, ST1DA2-V-F01, ST1RD2, ST1TD2

ST Series bus refreshing modules, Model(s): ST1PSD

ST Series digital-analog converter modules, Model(s): ST1DA1-I, ST1DA2-V

ST Series head modules, Model(s): ST1H-BT, ST1H-PB

ST Series input modules, Model(s): ST1X1616-DE1-S1, ST1X16-DE1, ST1X2-DE1, ST1X4-DE1

ST Series output modules, Model(s): ST1Y16-TE2, ST1Y16-TPE3, ST1Y2-R2, ST1Y2-TE2, ST1Y2-TE8, ST1Y2-TPE3

ST Series power feeding modules, Model(s): ST1PDD

ST Series SSI absolute encoder input modules, Model(s): ST1SS1

Terminal blocks, Model(s): IU2-36TB, IU2-50TB, IU2-96TB

Vision Sensors, Model(s): VS70 or VS70 SENSOR V70 or V70 SENSOR may be followed by additional alphanumeric suffixes

Vision Sensors, Model(s): VS80 or VS80 SENSOR V80 or V80 SENSOR may be followed by additional alphanumeric suffixes

Voltage transform units, Model(s): QE8WH4VT

- May be followed by 0 thru 9 and/or A thru Z which has no limitation in number of digits.

\$ - where * is optional and may be 0 to 9 incl., A to Z incl.

* - Models may be followed by a dash and two alphanumeric characters.

@ - Where "nnn" is an optional three-character alphanumeric suffix signifying bundle.

+ - Models may be followed by -C and/or a dash with two alphanumerics for alternate version type.

nn - Where nn denotes 01 thru 99.

Note - Above Listed models of MELSEC CC-Link, Q, CC-Link IE Field, iQ-R series may be followed by "(C)" at the end of product name as PWB coated models.

Last Updated on 2024-03-07

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL Solutions' Follow - Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL Solutions' Follow - Up Service. Always look for the Mark on the product.

UL Solutions permits the reproduction of the material contained in Product iQ subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from Product iQ with permission from UL Solutions" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "©2024 UL LLC."